

**TABLA DE CONTROLES REMOTOS POR MODELO DE
TV / DVD / CONVERTOR / VHS**

www.elreydelremoto.com.ar

TELEVISORES			
MARCA	MODELO	OBSERVACIONES	MODELO DE REMOTO
ACOUSTECH	ATC 6020-S		CODIGO 2625 / 21F29 / RM20
ADMIRAL	14TG141	RD3200	CODIGO 2554 / RM7A
ADMIRAL	14TG142AM	RD3410	CODIGO 2554 / RM7A
ADMIRAL	20TG201AS	RD3200	CODIGO 2554 / RM7A
ADMIRAL	20TG202AM	RD3410	CODIGO 2554 / RM7A
ADMIRAL	29TG2029		CODIGO 2751
ADMIRAL	32 CANALES		CODIGO 2471
ADMIRAL	AD13A		CODIGO 2471 / RC36B
ADMIRAL	AD20 20"		2471
ADMIRAL	AD20A		CODIGO 2471 / RC36B
ADMIRAL	CTV310 10"		NO HAY REEMP
ADMIRAL	SC200A COE		2554
ADMIRAL	T294		2790
ADMIRAL	T294A		CODIGO 2751 / RM7A
ADMIRAL	TG1029 A 29"		2554
ADMIRAL	TG1029A		CODIGO 2751 / RD3410
ADMIRAL	TG1401 COE		2657
ADMIRAL	TG141		2481
ADMIRAL	TG141 / 241		2657
ADMIRAL	TG141 / COE14"		2554
ADMIRAL	TG142AM		3134
ADMIRAL	TG142AM		2554
ADMIRAL	TG201 AMCO E 20"		2554
ADMIRAL	TG201 AS STCO 20" STEREO		2554
ADMIRAL	TG201AM		2554
ADMIRAL	TG201AS		2554
ADMIRAL	TG202AM		2554
ADMIRAL	TG203AM		CODIGO 2554 / RM7A
ADMIRAL	TG203AM		2570
ADMIRAL	TG2100A	PROBAR PRIMERO CON ESTE	CODIGO 2554 / RM7A
ADMIRAL	TG2100A		2755
ADMIRAL	TG2900A	RA3030E	CODIGO 2755
ADMIRAL	TGF2029A		CODIGO 3505 / RM7A
ADMIRAL	TKF2100A		2751
ADMIRAL	TKF2100A ST	RN3000K / RD3400	CODIGO 2784 / RM7A
ADMIRAL	TKF2500		2751
ADMIRAL	TKF3400		2554
ADMIRAL	TKF3400A	RD 3500 / PANTALLA PLANA	CODIGO 2751 / RM7A
ADMIRAL	TM1021A		CODIGO 2782 / RC41
ADMIRAL	TM1021A		2751
ADMIRAL	TSS2100A90J SLIM		CODIGO 2752 / RC 41
ADMIRAL	TSS2900A01J SLIM		CODIGO 2752 / RC 41
AIKO	1414/181		CODIGO 2895
AIKO	AK-1486		NOSE SABE REEMPLAZO

AIKO	AK-2121		CODIGO 2895
AIWA	RC8TV02		2464
AIWA	TV		2554
AIWA	TV-AR216RHA		CODIGO 2464
AKAI	32 CANALES		2464
AKAI		IGUAL AL DEWO 32CH	CODIGO 2471 / RC36B
AKIO	14TC90FR		2471
AKIO	20TC90FR		2627
AKIO	20TC91FR		CODIGO 2625 / 21F29 / RM20
AKIO	20TC91FR		2627
AKIO	33TC30		2625
AKIO	33TC91	29CH	CODIGO 2627 / RC1408
AKIO	33TC92		CODIGO 2469 / RC0402
AKIO	33TV92		CODIGO 2469 / RC0402
AKIO	33TV92		2627
AKIO	53TC60		NOSE SABE REEMPLAZO
AKIO	53TC91		2557
AKIO	53TC92		CODIGO 2469 / RC0402
AKIO	53TC92		2625
AKIO	AK-1384		NOSE SABE REEMPLAZO
AKIO	AK2086		2557
AKIO	AK-2086		CODIGO 2657 / RM7A
AKIO	AK2186		2657
AKIO	AK-2186		CODIGO 2657 / RM7A
ALFIDE	20-20		CODIGO 2752 / RC 41
ALFIDE	29-29		CODIGO 2752 / RC 41
ALFIDE	AL2010		2657
ALFIDE	W		CODIGO 2752 / RC 41
AOC	L37W431 PLASMA		2481
ASAHI	AL2020		2728/2754
ASAHI	TVP-021PF		POSIBLE C R CHASIS TV
ASAHI	TVX029BP		2970
ATORI	29 CANALES		2627
ATORI	ATC1392 MS		2481
ATORI	ATC1392MS	29 CH	CODIGO 2627 / RC1408
ATORI	ATC2192MS		2627
AUDINAC	2960 CINEMASTER		2627
AUDINAC	A-710	SLIM	CODIGO 2752 / RC 41
AUDINAC	AC 155 14"		2627
AUDINAC	AC131M		2657
AUDINAC	AC155	RC6155/6145	CODIGO 2783 / RM7A
AUDINAC	AC155		2627
AUDINAC	AC156	RC6155/6145	CODIGO 2783 / RM7A
AUDINAC	AC156		2657
AUDINAC	AC157		CODIGO 2657 / RM7A
AUDINAC	AC166		2657
AUDINAC	AC201M	29 CH	CODIGO 2627 / RC1408
AUDINAC	AC2184	RC6770	CODIGO 2554 / RM7A
AUDINAC	AC2184		2627
AUDINAC	AC245	RC6770	CODIGO 2783 / RM7A
AUDINAC	AC245		2657
AUDINAC	AC255	RC6145	CODIGO 2783 / RM7A
AUDINAC	AC255		2657
AUDINAC	AC256	RC6145/6146	CODIGO 2783 / RM7A
AUDINAC	AC256		2554

AUDINAC	AC257	RD3100J	CODIGO 2554 / RM7A
AUDINAC	AC257 20"		2657
AUDINAC	AR2020		2554
AUDINAC	RC2215C		2657
AUDINAC	ST2110	RD3976	CODIGO 2554 / RM7A
AUDINAC	ST2157	RD3100J	CODIGO 2554 / RM7A
AUDINAC	ST2157		2738/2990
AUDINAC	ST2160	RD3200	CODIGO 2554 / RM7A
AUDINAC	ST2960		CODIGO 2751
AUDIOLOGIC	14TVGX		CODIGO 2785 / JXMTF/RCU90 / JXMMA
AUDIOLOGIC	14ZU		2783
AUDIOLOGIC	20T 20"		2651/2666
AUDIOLOGIC	20TVGX		CODIGO 2785 / JXMTF/RCU90 / JXMMA
AUDIOLOGIC	20ZU		RM7A
AUDIOLOGIC	21TVGX		CODIGO 2785 / JXMTF/RCU90 / JXMMA
AUDIOLOGIC	2901TVGX		CODIGO 2785 / JXMTF/RCU90 / JXMMA
AUDIOLOGIC	2991FT		2657
AUDIOLOGIC	29FTVGX		CODIGO 2666 / AC2006
AUDIOLOGIC	29TVGX		CODIGO 2785 / JXMTF/RCU90 / JXMMA
AUDIOLOGIC	GA2191FT		CODIGO 2822/ CODIGO2666
AUDIOLOGIC	GA-9-2991FT		CODIGO 2822/ CODIGO2666
AUDIOLOGIC	RC41		2554
AUDIOLOGIC	T-14		RM7A
AURORA	DESCONOCIDO		2481
AURORA	MRT CT20D	CT200	CODIGO 2894
AURORA	MRT14		2554
AURORA	MRT1470	MENU AMARILLO	CODIGO 2781 / RC015
AURORA	MRT2004	MENU AMARILLO	CODIGO 2781 / RC015
AURORA	MRT2070	MENU AMARILLO	CODIGO 2781 / RC015
AURORA	MRT2071	MENU AMARILLO	CODIGO 2781 / RC015
BAK	BK-90GR		CODIGO 3142
BASIC LINE	20" AUCHAN		2642
BASIC LINE	21"		2657
BASIC LINE	29"		2657
BASIC LINE	29B1		CODIGO 2666 / AC2006
BASIC LINE	29B1		2894
BASIC LINE	BI-2910F		CODIGO 2666 / AC2006
BASIC LINE	BL2950ST		2642
BASIC LINE	BL-2950ST		CODIGO 2642
BASIC LINE	BL-29R		CODIGO 2776
BASIC LINE	MRT20D		2781
BASIC LINE	NEW		2642
BASIC LINE	SHTV31614		2736
BASIC LINE	SHTV31620	RH3411E	CODIGO 2956 / RM7A
BASIC LINE	SHTV31629		2657
BASIC LINE	SHTV31720	RH3411E	CODIGO 2956 / RM7A
BGH	BT1401B		CODIGO 3134
BGH	BT2001B		CODIGO 3134
BGH	BT2101S	CODIGO 2892 ORIGINAL / RC135	CODIGO 2787 / RC83
BGH	BT2109 USM		CODIGO 3572
BGH	BT2901S	CODIGO 2892 ORIGINAL / RC135	CODIGO 2787 / RC83
BGH	BT2909S		
BGH	BT3401S	CODIGO 2892 ORIGINAL / RC135	CODIGO 2787 / RC83
BLAZE	BL21FA	REMOTO PLACA TV UNIVERSAL	CODIGO 2980 / CODIGO 2754
BLAZE	M-2101	REMOTO PLACA TV UNIVERSAL	CODIGO 2980 / CODIGO 2754

BLAZE	M-2901	REMOTO PLACA TV UNIVERSAL	CODIGO 2980 / CODIGO 2754
BLAZE	M-2952	REMOTO PLACA TV UNIVERSAL	CODIGO 2980 / CODIGO 2754
BLUESKY	B2902		CODIGO 3155
BLUESKY	BL2950		CODIGO 2642
BLUESKY	BSL-28S	ORIG TECLAS COLOR	CODIGO 2880 / RC 105-212
BLUESKY	BT2981	CODIGO 2787 ORIGINAL / RC83	CODIGO 2892 / RC135
BLUESKY	TF-2188GM	PIDIO CRUZADO	CODIGO 2965
BLUESKY	TF-2988GM		CODIGO 2965
BLUESKY	TV20BLK		RC105- CODIGO 2470
BLUESKY	TVD-2901	TV MAS DVD	CODIGO 2889
BOWMAR	BTC6020S		CODIGO 2625 / 21F29 / RM20
BRANIFF	BR-6-2961 ST		CODIGO 2666 / AC2006
BRANIFF	BR-6-2961FT		CODIGO 2666 O CODIGO 3155
BRANIFF	NO HAY MODELO		CODIGO 3155
BRANIFF	NO HAY MODELO		CODIGO 2666 / AC2006
BRANIFF			CODIGO 3196
BRASSONIC	37SYCE-5		NO SE SABE REEMPLAZO
BRASSONIC	SP1422PN		CODIGO 2698 / RC 105
BROKSONIC	CTVG 4545		2751
BROKSONIC	CTVG 4545	CLOCK ABAJO DEL REMOTO	CODIGO 2652
BROKSONIC	CTVG-4545-LS	29 CH	CODIGO 2627 / RC1408
BROKSONIC	CTVG-4545-LST	CODIGO 2989 ORIGINAL	CODIGO 2789
BROKSONIC	CTVG-4545-LST		CODIGO 2753
BROKSONIC	CTVG 4545-LSTC		2627
BROKSONIC	CTVG-4545-LSTC		CODIGO 2753
BROKSONIC	CTVG-4563		CODIGO 2753
BROKSONIC	CTVG-5454		2753
BROKSONIC	CTVG-5454	TECLAS PP Y -/--	CODIGO 3186 / CODIGO2698 / RC105
BROKSONIC	CTVG-5454-LST	59CH	CODIGO 2989
BROKSONIC	CTVG-5463		2989
BROKSONIC	CTVG-5463		CODIGO 2753
BROKSONIC	CTVL-4545	CLOCK ABAJO DEL REMOTO	CODIGO 2652
BROKSONIC	CTVL-4545		2753
BROOKLINE	UDI14		2652
BROOKLINE	UDT-14 UDI-14		CODIGO 2895 DUDOSO
BROWMAR	BTC6020S		2553
BRU	ABC 25"		CODIGO 2554 / RM7A
BRU	B20T	RD3200	CODIGO 2783 / RM7A
BRU	B20T		2895
BRU	BRU 20 20"		2657
CCE	ETC		2574
CCE	FINO		2625
CCE	HPS1402	PARECIDO RC202	CODIGO 2725 / CODIGO 2574
CCE	HPS141		2751
CCE	HPS1470		2574
CCE	HPS1479	RC202	CODIGO 2725 / CODIGO 2574
CCE	HPS1480		2574
CCE	HPS1481		2574
CCE	HPS1490		2574
CCE	HPS14R		2439
CCE	HPS2007	RC202	CODIGO 2725 / CODIGO 2574
CCE	HPS2070		2574
CCE	HPS2080		2574
CCE	HPS2081		CODIGO 2574 / CODIGO 2725
CCE	HPS2090		2574

CCE	HPS2185	RC202	CODIGO 2725 / CODIGO 2574
CCE	HPS2780		2574
CCE	HPS2781		2574
CCE	HPS2980		2574
CCE	HPS2981		2574
CCE	MPS1423		3190
CCE	MPS2023		2439
CFK	TC374		RC105- CODIGO 2470
CITIZEN	JCTC1314		2574
CITIZEN	JCTV1314	RC9740	CODIGO 2794 / OLYMPIC / TAHOCI
CITIZEN	JCTV1547		CODIGO 2648 / RC18147
CITIZEN	JCTV1547		2794
CITIZEN	JCTV2120	RC9740	CODIGO 2794 / OLYMPIC / TAHOCI
CITIZEN	JCTV2120		2740
CITIZEN	JCTV3309		2794
CONSTEL	CTL-3STB21		CODIGO 2571
CONTEC	CE1318		2641
CONTINENTAL	CTV2180	46 CH	CODIGO 2641 / 16RM / FS092
CONTINENTAL	CTV2180		2666
CONTINENTAL	CTV2924	FS185	CODIGO 2661 / FS 222 / MK6A
CONTINENTAL	CTV2924		2641
CONTINENTAL	CTV5474	46 CH	CODIGO 2641 / 16RM / FS092
CONTINENTAL	CTV5490	46 CH	CODIGO 2641 / 16RM / FS092
CONTINENTAL	CTV5490		2624
CONTINENTAL	CTV5495	FS185	CODIGO 2661 / FS 222 / MK6A
CONTINENTAL	CTV5495		2641
CONTINENTAL	CTV5670	46 CH	CODIGO 2641 / 16RM / FS092
CONTINENTAL	CTV5679	46 CH	CODIGO 2641 / 16RM / FS092
CONTINENTAL	CTV5679		2451
CONTINENTAL	CTV5950	46 CH	CODIGO 2641 / 16RM / FS092
CONTINENTAL	CTV5995	FS185	CODIGO 2661 / FS 222 / MK6A
CONTINENTAL	CTV5995		2641
CONTINENTAL	CTV6597	FS185	CODIGO 2661 / FS 222 / MK6A
CONTINENTAL	CTV6597		2451
CONTINENTAL	ELECTRIC		2624
CONTINENTAL	TECLA BLANCA 100 CH		2657
CONTINENTAL	VCR1870AN		2648
CONTINENTAL	VCR4843		2556
CONTINENTAL ELECTRIC	CETV34614		CODIGO 2751 / RM7A
CONTINENTAL ELECTRIC	CETV34629		CODIGO 2751 / RM7A
COSMIC	1405		CODIGO 2554 / RM7A
COSMIC	1405		2556
COSMIC	2004		CODIGO 2554 / RM7A
CROW	2004		2657
CROW	CM5221ST		2657
CROW	CTV1445		2481
NOBLEX	CTV2139		2755
CROW	CTV2930F		2755
CROW	RC6145		3155
CROW	TC1432R		2657
CROWN	MP1001		CODIGO 2892 / RC135
CROWN	TC1332	46 CH	CODIGO 2625 / 21F29 / RM20
CROWN	TC1432R	46 CH	CODIGO 2625 / 21F29 / RM20
CROWN	TC2132R	46 CH	CODIGO 2625 / 21F29 / RM20
CROWN JAPAN	CR-CTV2930F		CODIGO3155

CROWN JAPAN	CTV2130F		CODIGO 2666 / AC2006
CROWN MUSTANG	1414RV		2625
CROWN MUSTANG	2002PLL		2625
CROWN MUSTANG	2404R		2481
CROWN MUSTANG	AC110		2657
CROWN MUSTANG	CM1403 RD		2657
CROWN MUSTANG	CM1403RD	TECLA ZAPPING	CODIGO 2782 / RC41
CROWN MUSTANG	CM1407	NUEVA VERSION	CODIGO 2665 / 20TC627
CROWN MUSTANG	CM1414RD	TECLA ZAPPING	CODIGO 2782 / RC41
CROWN MUSTANG	CM1414RD		2481
CROWN MUSTANG	CM-1414-RD		CODIGO 2782 / RC41
CROWN MUSTANG	CM-147 KAV		CODIGO 2666 / AC2006
CROWN MUSTANG	CM2001		2481
CROWN MUSTANG	CM2002		2470
CROWN MUSTANG	CM2002AV		CODIGO 2666 / AC2006
CROWN MUSTANG	CM2002R		CODIGO 2666 / AC2006
CROWN MUSTANG	CM2002RD	TECLA ZAPPING	CODIGO 2752 / RC 41
CROWN MUSTANG	CM2002RD		2481
CROWN MUSTANG	CM2002rm autoserch		2666/2752
CROWN MUSTANG	CM2002ST		CODIGO 2657 / RM7A
CROWN MUSTANG	CM2002ST		2648
CROWN MUSTANG	CM2003	TECLA ZAPPING	CODIGO 2782 / RC41
CROWN MUSTANG	CM2003		2481
CROWN MUSTANG	CM2005		CODIGO 2782 / RC41
CROWN MUSTANG	CM2005		2481
CROWN MUSTANG	CM2006M		2481
CROWN MUSTANG	CM2006R		CODIGO 2657 / RM7A
CROWN MUSTANG	CM2006R		2625
CROWN MUSTANG	CM2007	NUEVA VERSION	CODIGO 2665 / 20TC627
CROWN MUSTANG	CM2007R	CODIGO 3129 FORMA ORIGINAL	CODIGO 2657 / RM7A
CROWN MUSTANG	CM2007R VERSION 2	TECLA DORMIR	CODIGO 2782 / RC41
CROWN MUSTANG	CM2008	TECLA ZAPPING	CODIGO 2782 / RC41
CROWN MUSTANG	CM2008		2657
CROWN MUSTANG	CM2103	TECLA ZAPPING	CODIGO 2782 / RC41
CROWN MUSTANG	CM-216-KAV		CODIGO 2666 / AC2006
CROWN MUSTANG	CM-216-KAV PLANO 21"		2481
CROWN MUSTANG	CM-217		2822
CROWN MUSTANG	CM-217-KAV		CODIGO 2666 / AC2006
CROWN MUSTANG	CM2829RST		2976
CROWN MUSTANG	CM291K ST	PANTALLA PLANA	CODIGO 2666 / AC2006
CROWN MUSTANG	CM297-JFL		CODIGO 2666 / AC2006
CROWN MUSTANG	CM298KFL		CODIGO 2666 / AC2006
CROWN MUSTANG	CM29-KST		
CROWN MUSTANG	CM-3207-LC	LCD	NO HAY REEMP
CROWN MUSTANG	CM-5121-ST		2553
CROWN MUSTANG	CM-5121-ST		CODIGO 2752 / RC 41
CROWN MUSTANG	CM51J		CODIGO 2782 / RC41
CROWN MUSTANG	CM5421AV		CODIGO 2892
CROWN MUSTANG	CM5721AV		CODIGO 2892
CROWN MUSTANG	CM721JAV		CODIGO 2892
CROWN MUSTANG	CM721JAVC		CODIGO 2782 / RC41
CROWN MUSTANG	CM721TAV		CODIGO 2978
CROWN MUSTANG	CM721TAV		2481
CROWN MUSTANG	CM921		PLACA GENERICA
CROWN MUSTANG	CN21FL	PLATINUM	CODIGO 2752 / RC 41

CROWN MUSTANG	CR2001		2892
CROWN MUSTANG	CR2008		2470
CROWN MUSTANG	CR2801		2470
CROWN MUSTANG	CT1405R		CODIGO 2554
CROWN MUSTANG	CT1405		2553
CROWN MUSTANG	CT1405R	39 CH	CODIGO 2969
CROWN MUSTANG	CT1405R		2648
CROWN MUSTANG	CT1405R PLL	181 CH	CODIGO 2657 / RM7A
CROWN MUSTANG	CT1420		2554
CROWN MUSTANG	CT2001		2648
CROWN MUSTANG	CT2001R		CODIGO 2470 / RC105
CROWN MUSTANG	CT2001R		2956
CROWN MUSTANG	CT2004	125CH	CODIGO 2657 / RM7A
CROWN MUSTANG	CT2004		2470
CROWN MUSTANG	CT2004R	39CH	CODIGO 2969
CROWN MUSTANG	CT2004R		2625
CROWN MUSTANG	CT2004R		2969
CROWN MUSTANG	CT2004R PLL	125 CH	CODIGO 2782 / RC41
CROWN MUSTANG	CT2005		2657
CROWN MUSTANG	CT2101		CODIGO 2470 / RC105
CROWN MUSTANG	CT2101		2481
CROWN MUSTANG	CT2104R		CODIGO 2969
CROWN MUSTANG	CT2104R		2655
CROWN MUSTANG	CT2501		CODIGO 2470 / RC105
CROWN MUSTANG	CT2501		2627
CROWN MUSTANG	CT2501R		2655
CROWN MUSTANG	CT2801		2956
CROWN MUSTANG	CT2801R	VIEJA VERSION	CODIGO 2470 / RC105
CROWN MUSTANG	CT2801R PLL	NUEVA VERSION	CODIGO 2553 / RC181
CROWN MUSTANG	CT2829		CODIGO 2553 / RC181
CROWN MUSTANG	CT2829		2470
CROWN MUSTANG	CT2829RST		2553
CROWN MUSTANG	CT2901R	OTRA VERSION DE 125 CH	CODIGO 2553 / RC181
CROWN MUSTANG	CT2901R	OTRA VERSION DE 125 CH	CODIGO 2752 / RC 41
CROWN MUSTANG	CT2901R	VERSION DE POCOS CANALES	CODIGO 2470 / RC105
CROWN MUSTANG	CT2901R		2974
CROWN MUSTANG	CT3104R	39 CH	CODIGO 2969
CROWN MUSTANG	SIN MODELO 14"		CODIGO 2782 / RC41
CROWN MUSTANG	SIN MODELO 20"		CODIGO 2665 / 20TC627
CROWN MUSTANG	TC1332		2655/2782
CROWN MUSTANG	TC1432		2481
CROWN MUSTANG	TC2004		CODIGO 2657 / RM7A
CROWN MUSTANG	TC2004	TECLA ZAPPING	CODIGO 2782 / RC41
CROWN MUSTANG	TC2004		2625
CROWN MUSTANG	TC2005		2657
CROWN MUSTANG	TC2132R		2481
CROWN MUSTANG	TC2132R		2625
CROWN MUSTANG	TM1021		CODIGO 2657 / RM7A
CROWN MUSTANG	VP8820		2625
CROWN MUSTANG	ZAFIRO		CODIGO 2782 / RC41
DAENYX	1450		2481
DAENYX	2095	TECLA ZAPPING	CODIGO 2782 / RC41
DAENYX	2095		2657
DAENYX	2097	TECLA ZAPPING	CODIGO 2782 / RC41
DAENYX	2097		CODIGO 2657 / RM7A

DAENYX	2097		2481
DAENYX	CT2004R		2481/2657/2554
DAENYX	DCT1400M		2657
DAENYX	DCT1405		2657
DAENYX	DCT1405M	FUZZY	CODIGO 2657 / RM7A
DAENYX	DCT1450M	FUZZY	CODIGO 2657 / RM7A
DAENYX	DCT1470M	COMO EL RECOR	CODIGO 2977 / RC 105
DAENYX	DCT1470M		2657
DAENYX	DCT2000M	FUZZY	CODIGO 2657 / RM7A
DAENYX	DCT2000M		2470
DAENYX	ZAFIRO		2439
DAEWOO	3922		2657
DAEWOO	7020		2471
DAEWOO	7021		2471
DAEWOO	8820		2471
DAEWOO	DTH1400		2657
DAEWOO	DTH141	R-38T01	CODIGO 2450 / RC18147
DAEWOO	DTH141		2439
DAEWOO	DTH141C		3126
DAEWOO	DTH1427		2449
DAEWOO	DTH1427FS	R18C26	CODIGO 2648 / RC18147
DAEWOO	DTH1456		2648
DAEWOO	DTH1456FS	T.BLANCA 100CH	CODIGO 2648 / RC18147
DAEWOO	DTH1492		2740
DAEWOO	DTH14Q2		2648
DAEWOO	DTH14Q2FS		2444
DAEWOO	DTH201	R-38T01	CODIGO 2450 / RC18147
DAEWOO	DTH201		2444
DAEWOO	DTH201C		3126
DAEWOO	DTH2027FS	R18C26	CODIGO 2648 / RC18147
DAEWOO	DTH2027FS		2449
DAEWOO	DTH2044		2648
DAEWOO	DTH2049VS	59 CH	CODIGO 2551 / 27T08
DAEWOO	DTH2049VS		2625
DAEWOO	DTH2056		2627
DAEWOO	DTH2056FS	T.BLANCA 100CH	CODIGO 2648 / RC18147
DAEWOO	DTH2071FS		2740/2648
DAEWOO	DTH2092FF		2648
DAEWOO	DTH20Q2FS		CODIGO 2648 / RC18147
DAEWOO	DTH20Q2FS		2648
DAEWOO	DTH20T2		2444
DAEWOO	DTH20TZ45		2444
DAEWOO	DTH20VS		CODIGO 2648 / RC18147
DAEWOO	DTH211		CODIGO3126
DAEWOO	DTH211F	R-38T01	CODIGO 2450 / RC18147
DAEWOO	DTH2172FS		2444
DAEWOO	DTH2175		2648
DAEWOO	DTH21T2FS		CODIGO 2648 / RC18147
DAEWOO	DTH21T2FS		2648
DAEWOO	DTH2929	TECLA SOUND	CODIGO 2648 / RC18147
DAEWOO	DTH2929		2444
DAEWOO	DTH2965		2648
DAEWOO	DTH2975		2444
DAEWOO	DTH2975FS	AUTOSEARCH	CODIGO 2648 / RC18147
DAEWOO	DTH2999		2648

DAEWOO	DTH29S5		2648
DAEWOO	DTH29S6		2449/2450
DAEWOO	DTH29S7		2449/2450
DAEWOO	DTH29S8		2449/2450
DAEWOO	DTH8620		2648
DAEWOO	R7B		2449/2450
DAICHI	DA-2191F	REMOTO CHASIS TV	CODIGO 2980 / CODIGO 2754
DAICHI	DA-2199F	REMOTO CHASIS TV	CODIGO 2980 / CODIGO 2754
DAICHI	DA-2999F	REMOTO CHASIS TV	CODIGO 2980 / CODIGO 2754
DAIHATSU	DFT21A		CODIGO 2729
DAIHATSU	DFT29S		CODIGO 2729
DAIHATSU	PARECIDO DURABRAND		CODIGO 3170
DAYTEK	CT-1470		CODIGO 2776
DAYTEK	CTPF-2107T		
DAYTRON	BTC6020S		2625
DAYTRON	DCT1450M		2625
DAYTRON	DCT2001M	FUZZY	CODIGO 2657 / RM7A
DAYTRON	DCT2027		2657
DAYTRON	DCT2047	T.ROJA 29CH	CODIGO 2627 / RC1408
DAYTRON	DCT2050	FUZZY	CODIGO 2657 / RM7A
DAYTRON	DCT2050		2627
DAYTRON	DTH1349	29 CH	CODIGO 2627 / RC1408
DAYTRON	DTH1349V		2657
DAYTRON	DTH1427FS		CODIGO 2648 / RC18147
DAYTRON	DTH1444FS	46 CH	CODIGO 2625 / 21F29 / RM20
DAYTRON	DTH1446FJ		2627
DAYTRON	DTH1446FS	46 CH	CODIGO 2625 / 21F29 / RM20
DAYTRON	DTH1456		2625
DAYTRON	DTH14Z1		2648
DAYTRON	DTH2044FS	46 CH	CODIGO 2625 / 21F29 / RM20
DAYTRON	DTH2046FS	46 CH	CODIGO 2625 / 21F29 / RM20
DAYTRON	DTH2049V		2648
DAYTRON	DTH2056		2627
DAYTRON	DTH2071FS		2648
DAYTRON	DTH20Z1		2648
DAYTRON	DTH20Z175		2648
DAYTRON	DTH20Z1FS	69 CH	CODIGO 2648 / RC18147
DAYTRON	HCR10Z	RC9740	CODIGO 2794 / OLYMPIC / TAHOCI
DECTRON	DL 32C00P		2553
DECTRON	VTH9814		3115
DELOS	DTC1420RC	SIMIL.PHILCO	CODIGO 2625 / 21F29 / RM20
DELOS	DTC1420RC		2648
DELOS	DTC4014RC	ORIG LARGO CON LED	CODIGO 2644 / 21F29 / RM20
DELOS	DTC4020	SIMIL.PHILCO	CODIGO 2625 / 21F29 / RM20
DELOS	DTH1444FS	SIMIL.PHILCO	CODIGO 2625 / 21F29 / RM20
DELOS	DTH1444FS		2644
DELOS	DTH2044FS	SIMIL.PHILCO	CODIGO 2625 / 21F29 / RM20
DEWO	2012		2625
DEWO	3922		2629
DEWO	7020	T. NARANJA 32 CH	CODIGO 2471 / RC36B
DEWO	7021	T. NARANJA 32 CH	CODIGO 2471 / RC36B
DEWO	8320		2471
DEWO	8820		???
DEWO	DCL412	13 CH	CODIGO 2629
DEWO	DCL412EB		2470

DEWO	DTH20V5		2629
DEWO	GN218		2648
DEWO	GN21B	T. NARANJA 32 CH	CODIGO 2471 / RC36B
DEWO	TCR-2037		ANDA SOLO EL UNIVERSAL ONE FOR ALL
DEWO	TV6913	T. NARANJA 32 CH	CODIGO 2471 / RC36B
DEWO	TV8813		CODIGO 2698 / RC 105
DEWO	TV8820		CODIGO 2698 / RC 105
DEWO	VHP8620		2471
DEWO	VHP8813		2554
DEWO	VPH 8320	DUMONT	CODIGO 2553 / RC181
DEWO	VPH3922		CODIGO 2471 / RC36B
DEWO	VPH6913		2470
DEWO	VPH7014		2471
DEWO	VPH7020	T. NARANJA 32 CH	CODIGO 2471 / RC36B
DEWO	VPH8329		2471
DEWO	VPH8420		CODIGO 2657 / RM7A
DEWO	VPH8420		2471
DEWO	VPH8425		CODIGO 2657 / RM7A
DEWO	VPH8520		CODIGO 2657 / RM7A
DEWO	VPH8614		CODIGO 2657 / RM7A
DEWO	VPH8620		CODIGO 2657 / RM7A
DEWO	VPH8620		2738
DEWO	VPH8720		CODIGO 2782 / RC41
DEWO	VPH8720		2738
DEWO	VPH8814		CODIGO 2470 / RC105
DEWO	VPH8819		2481
DEWO	VPH8820		CODIGO 2470 / RC105
DEWO	VPH8821		CODIGO 2553 / RC181
DEWO	VPH8821		2655 /2470
DEWO	VPH8826		2738
DEWO	VPH9329		CODIGO 2470 / RC105
DEWO	VPH9420		2657
DEWO	VPH9620	T. NARANJA 100 CH	CODIGO 2553 / RC181
DEWO	VPH9620		2751
DEWO	VPH9720		CODIGO 2782 / RC41
DEWO	VPH9725		CODIGO 2553 / RC181
DEWO	VPH9729		2553
DEWO	VPH9814		CODIGO 2553 / RC181
DEWO	VTH9620		2974
DEWO			2629
DIPLOMATIC	2970		2553
DIPLOMATIC	14SYS		2642
DIPLOMATIC	20SYS		2738
DIPLOMATIC	DHPS1473		CODIGO 2725
DIPLOMATIC	DI2172ST		CODIGO 2642
DIPLOMATIC	DI2970ST		CODIGO 2642
DIPLOMATIC	GMTV114M		2738
DIPLOMATIC	GMTV120M		3185
DIPLOMATIC	GMTV121F		3185
DIPLOMATIC	GMTV14M		CODIGO 2785 / JXMFT / JXMMA
DIPLOMATIC	GMTV20M		CODIGO 2785 / JXMFT / JXMMA
DIPLOMATIC	GMTV21FN		CODIGO 2785 / JXMFT / JXMMA
DIPLOMATIC	GMTV21S		CODIGO 2785 / JXMFT / JXMMA
DIPLOMATIC	GMTV221S		3185
DIPLOMATIC	GMTV29FN		CODIGO 2785 / JXMFT / JXMMA

DIPLOMATIC		RC201	CODIGO 2725 / CCE
DREAN	14SYC		3185
DREAN	20SYC		2738
DREAN	BR 2053		CODIGO 2698 / RC 105
DREAN	CH1053	T. NARANJA 32 CH	CODIGO 2471 / RC36B
DREAN	CH2353 14"		2471
DREAN	CM1053		2738
DREAN	SMR142	FS185	CODIGO 2624 / FS 222 / MK6A
DREAN	SMR142		2471
DREAN	SMR202	FS185	CODIGO 2624 / FS 222 / MK6A
DREAN	SMR202		2451
DREAN	ST202		2451
DUMONT	100 CH		2471
DUMONT	32 CH		2641
DUMONT	K9115	T. NARANJA 32 CH	CODIGO 2471 / RC36B
DUMONT	K9320N		CODIGO 2553 / RC181
DURABRAND	4PS-2071/1471		2553
DURABRAND	CTV14NF		2725
DURABRAND	CTV14NF		CODIGO 3149 / CHASIS TV
DURABRAND	CTV20NF		2755
DURABRAND	CTV20NF		CODIGO 3149 / CHASIS TV
DURABRAND	CTV29NF		2728
DURABRAND	CTV29NF		CODIGO 3149 / CHASIS TV
DURABRAND	CY2915		CODIGO 3149 / CHASIS TV
DURABRAND	HPS1471	RC202	CODIGO 2725 / CCE
DURABRAND			CODIGO 2729
DYNASTY	14SYC		CODIGO 2738
DYNASTY	14SYC		2727
DYNASTY	20SYC		CODIGO 2738
DYNASTY	20SYC		2657
ELTEK	14RH	32CH	CODIGO 2471 / RC36B
ELTEK	CT-14RP	29 CH	CODIGO 2627 / RC1408
ELTEK	CT-14RP		2657
ELTEK	CT-20RP	29 CH	CODIGO 2627 / RC1408
EMERSON	EC2013	RC-235	CODIGO 2823
EMERSON	EM22941		3106
EMERSON	EMTV22021		CODIGO 2553 / RC181
EMERSON	EMTV22021		2974
EMERSON	EMTV22041		CODIGO 2657 / RM7A
EMERSON	EMTV31444		2553
EMERSON	EMTV32144		CODIGO 2553 / 2642 RC181
EMERSON	EMTV32541		CODIGO 2553 / RC181
EMERSON	EMTV32541		2974
EMERSON	EMTV32941		CODIGO 2553 / RC181
EMERSON	EMTV32948		2553
EMERSON	EN20B		CODIGO 2471 / RC36B
EMERSON	EN20B		2751
EMERSON	TC1369		CODIGO 2738
EMERSON	TC1369		2471
EMERSON	TC1969		CODIGO 2738
EMERSON	TC1969		2553
EMERSON	TC2555		CODIGO 2989
EMERSON	TC2555D		2553
EOLITE	PT LCD 27		2627
EOLITE	PT LCD 32		3106

EUROMAX	EM-1410		CODIGO 2978
EUROTECH	C/FUZZI		2989
EVIAN	???	K2107	CODIGO 2878
EVIAN	EV2107		2624
FIRST LINE	9114	FXFR	CODIGO 2559 / FXFR
FIRST LINE	29"		2657
FIRST LINE	BFP 2903		3155
FIRST LINE	BPF2103		CODIGO 3155
FIRST LINE	BPF2903		CODIGO 3155
FIRST LINE	BPF2903	OTRA VERSION	CODIGO 3196
FIRST LINE	BT2989		CODIGO 3196
FIRST LINE	BT3460A		
FIRST LINE	DCT1450M	FUZZY	CODIGO 2657 / RM7A
FIRST LINE	DCT1450M		2878
FIRST LINE	DCT2070M		2657
FIRST LINE	DTA1431FS		2657
FIRST LINE	DTH14J1		CODIGO 2648 / RC18147
FIRST LINE	DTH14J1FS		2648
FIRST LINE	DTH17J1		2648
FIRST LINE	DTH20J1		CODIGO 2648 / RC18147
FIRST LINE	DTH20J1FS		2648
FIRST LINE	TMT1459 FL		2648
FIRST LINE	TMT1459FL		CODIGO 2657 / RM7A
FIRST LINE	TMT2059FL		CODIGO 2657 / RM7A
FIRST LINE	TMT2059FL		2969
FIRST LINE	TMT2159FL		CODIGO 2657 / RM7A
FIRST LINE	TMT2859FL		CODIGO 2470 / RC105
FIRST LINE	TMT2859FL		2956
FISHER	9120	FXFR	CODIGO 2559 / FXFR
FISHER	FTM0121S		CODIGO 2559 / FXFR
FISHER	FTM0121S		CODIGO 2752 / RC 41
FISHER	FTM0121S		CODIGO 2554 / RM7A
FTM0129			2470
FISHER	FTM0129S		CODIGO 2554 / RM7A
FISHER	FTM0229		2751
FISHER	FTM0429		CODIGO 2559 / FXFR
FISHER	FTM6114	FXFR	CODIGO 2559 / FXFR
FISHER	FTM6120		CODIGO 2559 / FXFR
FISHER	FTM9114		2559
FISHER	FTM9120		2559
FISRT LINE	DCT2070M	FUZZY	CODIGO 2657 / RM7A
FLOWCAP	K-9115		2471
FREEWAY	RL1709		CODIGO 2698 / RC 105
FUJITRON	GN13A		CODIGO 2471 / RC36B
FUJITRON	GN22A		CODIGO 2471 / RC36B
FUJITRON	TECLA NARANJA 32 CANALES		2559
GENERAL ELECTRIC	2000		2471
GENERAL ELECTRIC	2910		2792
GENERAL ELECTRIC	1410		2833
GENERAL ELECTRIC	14000		2792
GENERAL ELECTRIC	14091		2792
GENERAL ELECTRIC	14700	FS207	CODIGO 2624 / FS 222 / MK6A
GENERAL ELECTRIC	14700		2555
GENERAL ELECTRIC	20000		2624
GENERAL ELECTRIC	20091		2475

GENERAL ELECTRIC	20094		2552 / 2555
GENERAL ELECTRIC	20700		2555
GENERAL ELECTRIC	21090		2624
GENERAL ELECTRIC	27184		2555
GENERAL ELECTRIC	27600		2689
GENERAL ELECTRIC	27602		2689
GENERAL ELECTRIC	29601		2689
GENERAL ELECTRIC	200945		2689
GENERAL ELECTRIC	2000ST		2555
GENERAL ELECTRIC	21090/1		2792
GENERAL ELECTRIC	2900 ST		2624
GENERAL ELECTRIC	2901ST		2452
GENERAL ELECTRIC	29184/601		2792
GENERAL ELECTRIC	BTC6020S	FS207	CODIGO 2624 / FS 222 / MK6A
GENERAL ELECTRIC	CRK64A1		2689
GENERAL ELECTRIC	GE 20000		CODIGO 2475
GENERAL ELECTRIC	GE 20091 ST		CODIGO 2555 / GE BLANCO MT
GENERAL ELECTRIC	GE1400	ORIGINAL 00021E	CODIGO 2792 / 00021E
GENERAL ELECTRIC	GE14091		CODIGO 2555 / GE BLANCO MT
GENERAL ELECTRIC	GE14700		CODIGO 2624 / FS 222 / MK6A
GENERAL ELECTRIC	GE2000	ORIGINAL 00021E	CODIGO 2792 / 00021E
GENERAL ELECTRIC	GE20700		CODIGO 2624 / FS 222 / MK6A
GENERAL ELECTRIC	GE2110		CODIGO 2833
GENERAL ELECTRIC	GE21600		CODIGO 2689 / RCA-III
GENERAL ELECTRIC	GE27600		CODIGO 2689 / RCA-III
GENERAL ELECTRIC	GE27602		CODIGO 2689 / RCA-III
GENERAL ELECTRIC	GE2901ST		CODIGO 2452
GENERAL ELECTRIC	GE2910ST		CODIGO 2833
GENERAL ELECTRIC	GE29184		CODIGO 2689 / RCA-III
GENERAL ELECTRIC	GE29601		CODIGO 2689 / RCA III
GENERAL ELECTRIC	GE33682		CODIGO 2689 / RCA-III
GENERAL ELECTRIC	GR2900		CODIGO 2452
GENERAL ELECTRIC	HIN5502ST		2555
GLOBAL HOME	21" GHF21		2689
GLOBAL HOME	GH.TV29RF		2776
GLOBAL HOME			CODIGO 3174
GOLDMUND	GD-TV21RF		2881
GOLDMUND	GD-TV29RF		2881
GOLDSTAR	4725		CODIGO 2641 / 16RM / FS092
GOLDSTAR	4745		CODIGO 2641 / 16RM / FS092
GOLDSTAR	4825		CODIGO 2641 / 16RM / FS092
GOLDSTAR	4825		3174
GOLDSTAR	14A80		2451
GOLDSTAR	14K70		2451
GOLDSTAR	20A80		2453
GOLDSTAR	20B80	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	20B80		2451
GOLDSTAR	20K70		2624
GOLDSTAR	B80181		2453
GOLDSTAR	CNT4172	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CNT4175	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CNT4745		2451
GOLDSTAR	CNT4825	FS092	CODIGO 2641 / 16RM / FS092
GOLDSTAR	CNT4825		2451
GOLDSTAR	CNT4900		2641

GOLDSTAR	CNT4905	FS092	CODIGO 2641 / 16RM / FS092
GOLDSTAR	CNT9075	FS207	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CNT9075		2451
GOLDSTAR	CNT9175	FS207	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CNT9825	FS092	CODIGO 2641 / 16RM / FS092
GOLDSTAR	CNT9905	FS092	CODIGO 2641 / 16RM / FS092
GOLDSTAR	CNT9905		2451
GOLDSTAR	CNZ4175	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CNZ4175		2451
GOLDSTAR	CP14A82	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP14B8011		2451
GOLDSTAR	CP14B80H	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP14BA80	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP14BA82	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP14BA82		2451
GOLDSTAR	CP20A82	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP20B8011		2451
GOLDSTAR	CP20B80H	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP20BA80	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP20BA82		2451
GOLDSTAR	CP20E4011	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP20E4011		2451
GOLDSTAR	CP20E40H		2624
GOLDSTAR	CP20F60		2624
GOLDSTAR	CP20J20P		2643
GOLDSTAR	CP20T20ST		2624
GOLDSTAR	CP20W4011		2624
GOLDSTAR	CP21C40	FS185	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP21D30		2624
GOLDSTAR	CP24		CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP25C10		2624
GOLDSTAR	CP29		CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP29		2773
GOLDSTAR	CP29C10		CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP29C34		2773
GOLDSTAR	CP29C36		2773
GOLDSTAR	CP29C40		2773
GOLDSTAR	CP29C40P		CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP29C42P		2643
GOLDSTAR	CP33C60P	CODIGO 2643 ORIGINAL	CODIGO 2624 / FS 222 / MK6A
GOLDSTAR	CP33C60P		2643
GOLDSTAR	CP34C62P		2643
GOLDSTAR	CPT34E62E		2643
GOLDSTAR	CTM4842		CODIGO 2898
GOLDSTAR	CVT2197		2643
GOLDSTAR	GHV1720A		2451
GOLDSTAR	RG21A		2556
GOLDSTAR	RG41A		2556
GOLDSTAR	RG941A		2556
GRADIENTE	GT1420		CODIGO 2624 / FS 222 / MK6A
GRADIENTE	GT1422		CODIGO 2624 / FS 222 / MK6A
GRADIENTE	GT2020		CODIGO 2624 / FS 222 / MK6A
GRADIENTE	GT2022		CODIGO 2624 / FS 222 / MK6A
GRADIENTE	HRM277S		2556
GRADIENTE	HRM299S		2458

GRADIENTE	HTM299S	IGUAL AL JVC	CODIGO 2432
GRADIENTE	JVCRMC423		2458
GRADIENTE	JVCRMC448/539		2458
GRADIENTE	JVCRMC471		2458
GRADIENTE	JVCRMC734		2458
GRUNDIG	140	TP610	CODIGO 2739 / TP610
GRUNDIG	141	TP610	CODIGO 2739 / TP610
GRUNDIG	141		2458
GRUNDIG	151	TP610	CODIGO 2739 / TP610
GRUNDIG	153	TP610	CODIGO 2739 / TP610
GRUNDIG	200	TP610	CODIGO 2739 / TP610
GRUNDIG	201	TP610	CODIGO 2739 / TP610
GRUNDIG	202	TP610	CODIGO 2739 / TP610
GRUNDIG	203		2739
GRUNDIG	213	TP610	CODIGO 2739 / TP610
GRUNDIG	401		2739
GRUNDIG	1411	TP622	CODIGO 2446 / TP622
GRUNDIG	1411		2739
GRUNDIG	1412	TP720	CODIGO 2447 / TP720
GRUNDIG	1412		2446
GRUNDIG	1511	TP622	CODIGO 2446 / TP622
GRUNDIG	1511		2447
GRUNDIG	1512	TP720	CODIGO 2447 / TP720
GRUNDIG	1512		2446
GRUNDIG	2011	TP622	CODIGO 2446 / TP622
GRUNDIG	2011		2447
GRUNDIG	2012	TP720	CODIGO 2447 / TP720
GRUNDIG	2012		2446
GRUNDIG	2031		2447
GRUNDIG	2045		2446
GRUNDIG	2112	TP720	CODIGO 2447 / TP720
GRUNDIG	2112		2788
GRUNDIG	2131		2447
GRUNDIG	2822		2446
GRUNDIG	3400		2447
GRUNDIG	4245		2739
GRUNDIG	6245		2788
GRUNDIG	281 CUC3800		2447
GRUNDIG	2822 CUC5360	TP663	CODIGO 2697
GRUNDIG	29"		2446
GRUNDIG	A2404		2481
GRUNDIG	A6100		TP390
GRUNDIG	A6400		2788
GRUNDIG	A7600		2788
GRUNDIG	A7800		2788
GRUNDIG	AGD8510		2788
GRUNDIG	CUC121		TP350
GRUNDIG	CUC200	TP622	CODIGO 2446 / TP622
GRUNDIG	CUC220		2446
GRUNDIG	CUC221		2788
GRUNDIG	CUC300	TP720	CODIGO 2447 / TP720
GRUNDIG	CUC300		2739
GRUNDIG	CUC3400	TP610	CODIGO 2739 / TP610
GRUNDIG	CUC3400		2446
GRUNDIG	CUC3800	TP660	CODIGO 2696

GRUNDIG	CUC3800		2739
GRUNDIG	CUC3840		2447
GRUNDIG	CUC5300		2446
GRUNDIG	F3020		2447
GRUNDIG	FE200		2788
GRUNDIG	GR143		CODIGO 2782 / RC41
GRUNDIG	GR143		2446
GRUNDIG	GR201	VERSION 1	CODIGO 2782 / RC41
GRUNDIG	GR201	VERSION 2	CODIGO 2782 / RC41
GRUNDIG	GR201		2481
GRUNDIG	GR201ST		2481
GRUNDIG	GR203		CODIGO 2782 / RC41
GRUNDIG	GR203	VERSION 2	CODIGO 2559 / FXFR
GRUNDIG	GR203		2481
GRUNDIG	GR203 T20-833S	VERSION 1	CODIGO 2782 / RC41
GRUNDIG	GR213 ST	VERSION 1	CODIGO 2782 / RC41
GRUNDIG	GR213ST		2443/2442
GRUNDIG	GR2893		CODIGO 2782 / RC41
GRUNDIG	GR293	NUEVA VERSION	CODIGO 2665 / 20TC627
GRUNDIG	GR293	VERSION 1	CODIGO 2782 / RC41
GRUNDIG	GR293		2481
GRUNDIG	GR293ST		2648
GRUNDIG	GR499		CODIGO 2782 / RC41
GRUNDIG	GSC200		2481
GRUNDIG	GTR14PF	NUEVO FLAT	CODIGO 2666 / AC2006
GRUNDIG	GTR21PF	NUEVO FLAT	CODIGO 2666 / AC2006
GRUNDIG	GTR-29NL		TP200
GRUNDIG	GTR29PF	NUEVO FLAT	CODIGO 2666 / AC2006
GRUNDIG	MRT2004		2822
GRUNDIG	MRT-2521		CODIGO 2781
GRUNDIG	P40-040		2554
GRUNDIG	P40-245EURO		2447
GRUNDIG	SC1516		2739
GRUNDIG	ST28-803-S		2788
GRUNDIG	ST3020		2481
GRUNDIG	ST3022		2788
GRUNDIG	T55-345		2788
GRUNDIG	TV381	TP660	CODIGO 2696
GRUNDIG	VCR292		2739
GRUNDIG	VCR384		2556
GRUNDIG	VS290		2556
GRUNDIG	VS294		2556
GUEST	OS1402MN		2556
HANNOVER	DTH-2440		CODIGO 2625 / 21F29 / RM20
HANNOVER	DTH-2440		2657
HANNOVER	OLYMPIC RC6770		2644
HAYSI	M 2952	PLACA UNIVERSAL	CODIGO 2980 / CHASIS TV UNIV
HAYSI	M-2101	PLACA UNIVERSAL	CODIGO 2980 / CHASIS TV UNIV
HITACHI	1450		3106
HITACHI	2011		2624
HITACHI	2040		2443
HITACHI	2051		2468
HITACHI	20550ST		2624
HITACHI	29"	CLE-935	
HITACHI	29GFS12		2571

HITACHI	CD		3545
HITACHI	CDH14BM3	BANANITA ORIGINAL	CODIGO 2735 / RC915
HITACHI	CDH-14BM3A		2900
HITACHI	CDH-14GXM1A		2571
HITACHI	CDH14GXM3	BANANITA ORIGINAL	CODIGO 2735 / RC915
HITACHI	CDH14GXM5		CODIGO 2735 / RC915
HITACHI	CDH20BM2		CODIGO 2735 / RC915
HITACHI	CDH20BM3	BANANITA ORIGINAL	CODIGO 2735 / RC915
HITACHI	CDH-20BM3A		2571
HITACHI	CDH20GM2	BANANITA ORIGINAL	CODIGO 2735 / RC915
HITACHI	CDH-20GM2		2571
HITACHI	CDH20GM4		CODIGO 2735 / RC915
HITACHI	CDH-20GM5		2571
HITACHI	CDH20GM7		CODIGO 2735/ RC915
HITACHI	CDH20GM9		CODIGO 2735 / RC915
HITACHI	CDH20GXM1	BANANITA ORIGINAL	CODIGO 2735 / RC915
HITACHI	CDH20GXM1A		2571
HITACHI	CDH21BM4	BANANITA ORIGINAL	CODIGO 2735 / RC915
HITACHI	CDH21BM4		2571
HITACHI	CDH-21BUS2		3525
HITACHI	CDH21GFS10	TELE NUEVA FLAT	CODIGO 2879
HITACHI	CDH21GFS12		2573-2571
HITACHI	CDH-21GFS12	CODIGO 3545 (CON ESTE SE ENTRA AL MODO	3545
HITACHI	CDH-21GF312		3545
HITACHI	CDH21GFS4	TELE NUEVA FLAT	CODIGO 2879
HITACHI	CDH21GFS4		2571
HITACHI	CDH21GFS6	TELE NUEVA FLAT	CODIGO 2879
HITACHI	CDH21GFS8	TELE NUEVA FLAT	CODIGO 2879
HITACHI	CDH21GM2		CODIGO 2735 / RC915
HITACHI	CDH21GS2	BANANITA ORIGINAL	CODIGO 2735 / RC915 / RC914
HITACHI	CDH21GS2		3545
HITACHI	CDH21GS8		CODIGO 2735 / RC915
HITACHI	CDH29GF4		2571
HITACHI	CDH-29GFS12		2735
HITACHI	CDH-29GFS12		3545
HITACHI	CDH29GFS2		2879
HITACHI	CDH29GFS6		2879
HITACHI	CDH29GS2		CODIGO 2735 / RC915
HITACHI	CDH29GS4	29 "	CODIGO 2735 / RC915
HITACHI	CDH29GS5	29 "	CODIGO 2735 / RC915
HITACHI	CDH29GS7 ST		CODIGO 2735 / RC915
HITACHI	CDH-L32S02	HDMI	3177
HITACHI	CDH-L47F02		3548
HITACHI	CDH-L32F02		3548
HITACHI	CDH-L24F02		3548
HITACHI	CDT1500		2573
HITACHI	CNT-4172		2443
HITACHI	CNT-4175		2661
HITACHI	CNT-4825		2661
HITACHI	CNT-4905		2641
HITACHI	CNT-9175		2641
HITACHI	CNT-9325		2661
HITACHI	CNT-9825		2641
HITACHI	CNT-9905		2641
HITACHI	CP14A80		2641

HITACHI	CP14A82		2661
HITACHI	CP14B70		2661
HITACHI	CP14B80H		2624
HITACHI	CP14B90		2624
HITACHI	CP14E40H		2624
HITACHI	CP14J20		2624
HITACHI	CP20A80		2624
HITACHI	CP20B20		2451
HITACHI	CP20B70		2624
HITACHI	CP20B80H		2624
HITACHI	CP20E40H		2624
HITACHI	CP20J20		2624
HITACHI	CP21B30		2624
HITACHI	CP25C10		2624
HITACHI	CP29C10		2773
HITACHI	CP29C34		2773
HITACHI	CP29C36		2773
HITACHI	CPT1410	CLE891	NCODIGO 2443
HITACHI	CPT1410		2773
HITACHI	CPT1411	13CH	CODIGO 2860
HITACHI	CPT1420	CR912	CODIGO 2568 / RC0808
HITACHI	CPT1420		2443
HITACHI	CPT1420R	CR910	CODIGO 2568 / RC0808
HITACHI	CPT1430	CR913	CODIGO 2468 / RC913
HITACHI	CPT1430 1430R		2568
HITACHI	CPT1430R	CR913	CODIGO 2468 / RC913
HITACHI	CPT1430SR		CODIGO 2468 / RC913
HITACHI	CPT1445 RB		2468
HITACHI	CPT1445RB		CODIGO 2624 / FS 222 / MK6A
HITACHI	CPT1450R		CODIGO 2735 / RC915
HITACHI	CPT1450R		2624
HITACHI	CPT14SXM1		2571/2735
HITACHI	CPT2000		2571/2735
HITACHI	CPT2011	CR230	CODIGO 2900
HITACHI	CPT2020/2020R		2443
HITACHI	CPT2020R	CR910	CODIGO 2568 / RC0808
HITACHI	CPT2030		2568
HITACHI	CPT2030R	CR913	CODIGO 2468 / RC913
HITACHI	CPT2030SR	CR913	CODIGO 2468 / RC913
HITACHI	CPT2030SR		2468
HITACHI	CPT2040R		CODIGO 2624 / FS 222 / MK6A
HITACHI	CPT2040R		2468
HITACHI	CPT2040RN		2624
HITACHI	CPT2045RB		CODIGO 2624 / FS 222 / MK6A
HITACHI	CPT2050R		CODIGO 2735 / RC915
HITACHI	CPT2050R		2624
HITACHI	CPT2051R		CODIGO 2571 / RC914
HITACHI	CPT2051R		2571/2735
HITACHI	CPT2051RE		2571/2735
HITACHI	CPT2052/N	13 CH	CODIGO 2860
HITACHI	CPT2052R		2571
HITACHI	CPT2055R		2624
HITACHI	CPT2055SR		CODIGO 2735 / RC915
HITACHI	CPT20SXM1		CODIGO 2735 / RC915
HITACHI	CPT20SXM1		2571

HITACHI	CPT2100	CR230	CODIGO 2900
HITACHI	CPT2100		2735
HITACHI	CPT2110	CR230	CODIGO 2900
HITACHI	CPT2110		2443
HITACHI	CPT2111		2443
HITACHI	CPT2112R		2443
HITACHI	CPT21212SR	CR912	CODIGO 2568 / RC0808
HITACHI	CPT2121R	CR910	CODIGO 2568 / RC0808
HITACHI	CPT2121R		2443
HITACHI	CPT2122SR	CR910	CODIGO 2568 / RC0808
HITACHI	CPT2130	CR913	CODIGO 2468 / RC913
HITACHI	CPT2130		2568
HITACHI	CPT2130SR	CR913	CODIGO 2468 / RC913
HITACHI	CPT2150SER		2468
HITACHI	CPT2150SR		CODIGO 2735 / RC915
HITACHI	CPT2155SR		CODIGO 2571 / RC914
HITACHI	CPT21BI55		2571
HITACHI	CPT21BXM1		CODIGO 2735 / RC 915
HITACHI	CPT2400		CODIGO 2860
HITACHI	CPT2400		2571
HITACHI	CPT2929		2629
HITACHI	CPT2930SR	CODIGO 2773	CODIGO 2624 / FS 222 / MK6A
HITACHI	CPT2930SR		2468
HITACHI	CPT2933B		2773
HITACHI	CPT2933SR		CODIGO 3122
HITACHI	CPT2945SR	MENU	CODIGO 2887
HITACHI	CPT2945SR		2443/2442
HITACHI	CPT2950SR	PIP CON VCR	CODIGO 2573
HITACHI	CPT2955SR	PIP CON VCR	CODIGO 2573
HITACHI	CPT2992	MENU	CODIGO 2887
HITACHI	CPT2992		2468
HITACHI	CPT3345SR	MENU	CODIGO 2887
HITACHI	CR910		2468
HITACHI	CTP-1430		2568
HITACHI	CTP2011R		2468
HITACHI	CTP-2030R		2468
HITACHI	CTP2052		2468
HITACHI	CTP-2130		2468
HITACHI	CTP2950SRP	PIP CON VCR	CODIGO 2573
HITACHI	CTP3345SR		2468
HITACHI	CTP450RE		2468
HITACHI	F29-100	COMPRO PART	CODIGO 2573
HITACHI			CODIGO 2735 / RC 915
HI-TECH	LCD		2657
HOWLAND	HL-1400 NF		
HOWLAND	HL-2100 PF		CODIGO 2774
HOWLAND	HL-2100 PF		2571
HOWLAND	HL-2900 PF		
HOWLAND	HL-3400 PF		CODIGO 2878
HOWLAND			CODIGO 3522
HQS	CT1410		CODIGO 2785 / JXMFT
HQS	CT1410		2774
HQS	CT2010		2560
HQS	CT2110		2559
HQS	CT2116F		CODIGO 2785 / JXMFT

HQS	CT2910		CODIGO 2782 / RC41
HQS	CT2916F		CODIGO 2785 / JXMFT
HQS	TQ1814		CODIGO 2785 / JXMFT
HQS	TQ1814		2784
HQS	TQ1820		CODIGO 2785 / JXMFT
HYPSON	HYDFSR0054ESA		2560
HYUNDAI	CTV-H21NF		2725
HYUNDAI	CTV-H29PF		POSIBLE CODIGO 2899
HYUNDAI	CTV-H29NF		31324
INTERNACIONAL	RC4020		POSIBLE CODIGO 2470
IOCI	TC2157MS		2729
ITT	3350	NO SE CONSIGUE	
ITT/NOKIA/DREAN	9401		2627
ITT/NOKIA/DREAN	141TR		2838
ITT/NOKIA/DREAN	252CR CO		2557
ITT/NOKIA/DREAN	29"		2554
ITT/NOKIA/DREAN	FUZZY		2657
ITT/NOKIA/DREAN	RC1053		2657
ITT/NOKIA/DREAN	SAT141		2439
ITT/NOKIA/DREAN	SAT142		CODIGO 2667 / RC0422
ITT/NOKIA/DREAN	SAT143	CODIGO 2839 (FORMA ORIGINAL)	CODIGO 2469 / RC0402
ITT/NOKIA/DREAN	SAT144	FUZZY	CODIGO 2657 / RM7A
ITT/NOKIA/DREAN	SAT145	RC6145	CODIGO 2657 / RM7A
ITT/NOKIA/DREAN	SAT146		CODIGO 2648 / RC18147
ITT/NOKIA/DREAN	SAT146		2990
ITT/NOKIA/DREAN	SAT201		CODIGO 2667 / RC0422
ITT/NOKIA/DREAN	SAT201		2481
ITT/NOKIA/DREAN	SAT202		CODIGO 2557
ITT/NOKIA/DREAN	SAT202		2667
ITT/NOKIA/DREAN	SAT203	CODIGO 2839 (FORMA ORIGINAL)	CODIGO 2469 / RC0402
ITT/NOKIA/DREAN	SAT203		2557
ITT/NOKIA/DREAN	SAT204	FUZZY	CODIGO 2657 / RM7A
ITT/NOKIA/DREAN	SAT204		2557
ITT/NOKIA/DREAN	SAT205		CODIGO 2657 / RM7A
ITT/NOKIA/DREAN	SAT206		CODIGO 2648 / RC18147
ITT/NOKIA/DREAN	SAT206		2870
ITT/NOKIA/DREAN	SAT210		CODIGO 2667 / RC0422
ITT/NOKIA/DREAN	SAT210		2648
ITT/NOKIA/DREAN	SAT220		CODIGO 2667 / RC0422
ITT/NOKIA/DREAN	SAT221	CODIGO 2839 (FORMA ORIGINAL)	CODIGO 2469 / RC0402
ITT/NOKIA/DREAN	SAT221		2667
ITT/NOKIA/DREAN	SAT243		CODIGO 2469 / RC0402
ITT/NOKIA/DREAN	SAT243		2557
ITT/NOKIA/DREAN	SAT251		CODIGO 2838
ITT/NOKIA/DREAN	SAT251		2444
ITT/NOKIA/DREAN	SAT252		CODIGO 2648 / RC18147
ITT/NOKIA/DREAN	SAT290		CODIGO 2838
ITT/NOKIA/DREAN	SAT291		CODIGO 2648 / RC18147
ITT/NOKIA/DREAN	SAT291		2557
ITT/NOKIA/DREAN	SAT292		CODIGO 2648 / RC18147
ITT/NOKIA/DREAN	SAT293		CODIGO 2648 / RC18147
ITT/NOKIA/DREAN	SAT294		CODIGO 2648 / RC18147
ITT/NOKIA/DREAN	SAT320	NOBLEX SIN VIDEO	CODIGO 2469 / RC0402
ITT/NOKIA/DREAN	SAT320		2444
ITT/NOKIA/DREAN	SAT321	RC6145	CODIGO 2657 / RM7A

ITT/NOKIA/DREAN	SAT321		2557
ITT/NOKIA/DREAN	SAT421		CODIGO 2657 / RM7A
ITT/NOKIA/DREAN	SAT421		2738
ITT/NOKIA/DREAN	SAT521	RD3100J	CODIGO 2657 / RM7A
ITT/NOKIA/DREAN	SAT521		2990
ITT/NOKIA/DREAN	SW1000	TELE 10" JAPONESA	NO SE SABE REEMPLAZO
JVC	2196	TIPO PALETA	CODIGO 2458 / PALETA
JVC	21MT16		CODIGO 2821
JVC	2973AR		2990
JVC	AV2186	RMC441/445	CODIGO 2458 / PALETA
JVC	AV2186		2433
JVC	AV2192	PALETA	CODIGO 2458 / PALETA
JVC	AV2196	RMC441/445	CODIGO 2458 / PALETA
JVC	AV2973AN	CRUZ BLANCA	CODIGO 2458 / PALETA
JVC	AV2982		2458
JVC	AV-29MT16		CODIGO 2821
JVC	AV3352		2561
JVC	AV3352S	RMC423	CODIGO 2458 / PALETA
JVC	AV-T2122		CODIGO 2458 / PALETA
JVC	AV-T2912		2433
JVC	AV-T2912	CODIGO 2561 ORIG	CODIGO 2458 / PALETA
JVC	AV-T2982		2561
JVC	AV-T3493	TECLAS CELESTES	CODIGO 2458 / PALETA
JVC	AV-T3493 ST		2432
JVC	AV-T3893		2458
JVC	C1454		2561
JVC	C1463AR	RMC423	CODIGO 2458 / PALETA
JVC	C1463AR		2433
JVC	C1484	RMC471	CODIGO 2458 / PALETA
JVC	C1484		2433
JVC	C1486	TIPO PALETA	CODIGO 2458 / PALETA
JVC	C1486		2432
JVC	C1491		2458
JVC	C2031		2458
JVC	C2091		2458
JVC	C2116		CODIGO 2458 / PALETA
JVC	C21163AR		2458
JVC	C2163AC	RMC423	CODIGO 2433 / PALETA
JVC	C2184	RMC471	CODIGO 2458 / PALETA
JVC	C2186		CODIGO 2458 / PALETA
JVC	C2186AR		2432
JVC	CT1421		2458
JVC	CT1491	PALETA	CODIGO 2458 / PALETA
JVC	CT1491		2775
JVC	CT149E		2432
JVC	CT2021		CODIGO 2775
JVC	CT2021		2432
JVC	CT2091	PALETA	CODIGO 2458 / PALETA
JVC	CT2091		2775
JVC	CT2121		2432
JVC	KEIO		2775
JVC	PT2982		CODIGO 2458 / PALETA
JVC	PT2982		2783
JVC	RMC374		2458
JVC	RMC539		2561

JVC	T2912	CRUZ BLANCA	CODIGO 2458 / PALETA
JVC	T2982		2561
KEIO	9020		CODIGO 2554 / RM7A
KEIO	K1490		2561
KEIO	K2090		2554
KEIO	K9020		2554
KEIO	K9021		2657
KEN BROWM	141TR		2651
KEN BROWM	201TR		2789
KEN BROWM	21D4		2789
KEN BROWM	21F58		2651/2822
KEN BROWM	263TR		2467
KEN BROWM	HPS2071		2775
KEN BROWM	KB2120ST		2725
KEN BROWM	KB2123 FLAT		2666
KEN BROWM	KB-2-2121FT		3514
KEN BROWM	KB-2-21SLIM		2666
KEN BROWM	KB-2-21SLIMB		3514
KEN BROWM	KB2900		3514
KEN BROWM	KB2920ST		2642
KEN BROWM	KB2921ST		2642
KEN BROWM	KB2924ST		2642
KEN BROWM	KV-2-2923FT		2642
KEN BROWM	M2988		3514
KEN BROWM	TKB2138		2642
KEN BROWM	TKB2968		2467
KEN BROWM	TO2188ST		2642
KEN BROWM	TS1470		2467
KEN BROWN	2988		CODIGO 2651 / RC55 / SD SYSTEM
KEN BROWN	141TR	CODIGO 2789	CODIGO 2989
KEN BROWN	201TR	CODIGO 2789	CODIGO 2989
KEN BROWN	263TR		CODIGO 2775
KEN BROWN	EST 2098	SLIM	??
KEN BROWN	EST 2920	SLIM	??
KEN BROWN	EST 2921	SLIM	??
KEN BROWN	HPS1471		CODIGO 2725 / CCE
KEN BROWN	KB2120ST	KB2900	CODIGO 2642 / KB2900
KEN BROWN	KB2122ST		CODIGO 2642 / KB2900
KEN BROWN	KB2-14SLIM	LARGUITO TECLES CELESTES FUNCION TUV - EQ - SVHS	CODIGO 3514 CODIGO 2881
KEN BROWN	KB2-14SLIM-B	LARGUITO TECLES CELESTES FUNCION TUV - EQ - SVHS	CODIGO 3514 CODIGO 2881
KEN BROWN	KB-2-2120ST	CODIGO 2666 / AC2006	CODIGO 2822 / CODIGO 2976
KEN BROWN	KB-2-2120ST (OTRA VERSION)	CODIGO 3514	CODIGO 3514 CODIGO 2881
KEN BROWN	KB-2-2121ST	CODIGO 2666 / AC2006	CODIGO 2822 / CODIGO 2976
KEN BROWN	KB-2-2123FT		CODIGO 3514 CODIGO 2881
KEN BROWN	KB-2-2125FT	CODIGO 2666 / AC2006	CODIGO 2822 / CODIGO 2976
KEN BROWN	KB2-21SLIM	LARGUITO TECLES CELESTES FUNCION TUV - EQ - SVHS	CODIGO 3514 CODIGO 2881
KEN BROWN	KB2-21SLIM-B	LARGUITO TECLES CELESTES FUNCION TUV - EQ - SVHS	CODIGO 3514 CODIGO 2881
KEN BROWN	KB-2-2920ST	CODIGO 3514	CODIGO 3514 CODIGO 2881
KEN BROWN	KB-2-2920ST (OTRA VERSION)	CODIGO 2666 / AC2006	2822
KEN BROWN	KB-2-2921FT	CODIGO 2666 / AC2006	CODIGO 2822 / CODIGO 2976
KEN BROWN	KB-2-2921FT	2666	2666
KEN BROWN	KB-2-2923FT		CODIGO 3514
KEN BROWN	KB2-29SLIM	LARGUITO TECLES CELESTES FUNCION TUV - EQ - SVHS	CODIGO 3514 CODIGO 2881
KEN BROWN	KB2-29SLIM-B	LARGUITO TECLES CELESTES FUNCION TUV - EQ - SVHS	CODIGO 3514 CODIGO 2881
KEN BROWN	KB-2-3421FT	CODIGO 2666 / AC2006	CODIGO 2822 / CODIGO 2976

KEN BROWN	KB2920ST	SEMIPLANO	CODIGO 2642 / KB2900
KEN BROWN	KB2921-98	REMOTO HITACHI RC915	CODIGO 2735
KEN BROWN	TA-2931FT		CODIGO 2467
KEN BROWN	TKB2122		CODIGO 2666 / AC2006
KEN BROWN	TKB2128	KB1421	CODIGO 2467 / KB1421
KEN BROWN	TKB2138	KB1421	CODIGO 2467 / KB1421
KEN BROWN	TKB2158	KB1421	CODIGO 2467 / KB1421
KEN BROWN	TKB2168	KB1421	CODIGO 2467 / KB1421
KEN BROWN	TKB2178	KB1421	CODIGO 2467 / KB1421
KEN BROWN	TKB2178	KB2900	CODIGO 2642 / KB2900
KEN BROWN	TKB2968		CODIGO 2467 / KB1421
KEN BROWN	TVS-2910FS (BRASILERO)	RC-211	FUNCIONA CON RC105
KENIA	2014		2776
KENIA	3712		2661
KENIA	5045		2641
KENIA	3060K-C5071K	NOBLEX SIN VIDEO	CODIGO 2469 / RC0402
KENIA	C1400K		2641
KENIA	C-1400K	FS185E	CODIGO 2624 / FS 222 / MK6A
KENIA	C3025K	FS185E	CODIGO 2624 / FS 222 / MK6A
KENIA	C3025K		2661
KENIA	C3045		2624
KENIA	C3045K		CODIGO 2641 / 16RM / FS092
KENIA	C3050		2641
KENIA	C3050K		CODIGO 2624 / FS 222 / MK6A
KENIA	C3060K		2661
KENIA	C5071K		2839
KENIA	C5081		2557
KENIA	C5081K		CODIGO 2624 / FS 222 / MK6A
KENIA	C7029K		2624
KENIA	C7129K		CODIGO 2624 / FS 222 / MK6A
KENIA	C7129K		2838
KENIA	C7129K		2773
KENIA	VCK201		2624
KENIA	VCK401		2556
KENIA			CODIGO 2624 / FS 222 / MK6A
KILEI	SC3710		NO HAY REEMP
KIREY	CTV1498		2790
KNEISSEL	FCRT29STC		CODIGO 3196
KNEISSEL	PARECIDO AL 3155		CODIGO 3155
KNEISSEL	PARECIDO AL 3196		CODIGO 3196
KOBLENZ (CASA DEL AUDIO)			CODIGO 2978
KONKA	K1416L		2556
KORTING			2755
KOTRON	2003		2969
KOTRON	IGUAL AL WINCO	RC235	CODIGO 2823
KOTRON	P1401MN	RC235	CODIGO 2823
KOTRON	P2001	RC235	CODIGO 2823
KTV	14POC		2471
KTV			2823
KTV	8820		CODIGO 2470 / RC105
KTV	20TOC	RC9740	CODIGO 2794
L G	CP34C62P		POSIBLE 2733
LARK DIGITAL	LDT1408M 14"		2657
LARK DIGITAL	LDT2108S 21"		3185
LARK DIGITAL	LDT2118F 21"		3185

LG	2155		3185
LG	14D90CR	FS207	CODIGO 2624 / FS 222 / MK6A
LG	14K40	LG008	CODIGO 2624 / FS 222 / MK6A
LG	14K60		CODIGO 2624 / FS 222 / MK6A
LG	20K40	LG008	CODIGO 2624 / FS 222 / MK6A
LG	20K60		CODIGO 2624 / FS 222 / MK6A
LG	20K70	LG008	CODIGO 2624 / FS 222 / MK6A
LG	29FS7RL		POSIBLE 2733
LG	CP14D90		2624
LG	CP17J20	FS207	CODIGO 2624 / FS 222 / MK6A
LG	CP20 MORC		2624
LG	CP20B08H	FS207	CODIGO 2624 / FS 222 / MK6A
LG	CP20D90	FS207	CODIGO 2624 / FS 222 / MK6A
LG	CP20F60	LG008	CODIGO 2624 / FS 222 / MK6A
LG	CP20J20	LG008	GRU
LG	CP20J20P	FS207	CODIGO 2624 / FS 222 / MK6A
LG	CP20J50		CODIGO 2733
LG	CP20K40	LG008	CODIGO 2624 / FS 222 / MK6A
LG	CP20K70		2624
LG	CP20T20	FS207	CODIGO 2453 / FS 222
LG	CP20T20		2624
LG	CP21D30M	FS207	CODIGO 2453 / FS 222
LG	CP21D30ST	FS207	CODIGO 2453 / FS 222
LG	CP21D30ST		2624
LG	CP25Q20		CODIGO 2643 / FS 222
LG	CP29C34H	FS207	CODIGO 2453 / FS 222
LG	CP29C34H		2624
LG	CP29K40		2624
LG	CPC1450R		2624
LG	CPC2050R		2624
LG	CPC2051		2624
LG	CPC2055CK		2624
LG	CPC2150SCR		2624
LG	CPC2155		2624
LG	CPC2155SCR		2624
LG	K40	LG008	CODIGO 2453 / FS 222
LG	RP-21FD15		POSIBLE 2733
LG	RP29FE80	TV+HOME PANTALLA PLANA	NO HAY REEMP
LIBERTY	GRIS		2624
LIBERTY	LYMX		2439
LYNX	LYF29		CODIGO 2776
MAGNATECH	MT1300R		CODIGO 2657 / RM7A
MAGNATECH	MT1300R	RC9740	CODIGO 2794
MAGNATECH	MT2200R		CODIGO 2794
MAKROSONIC	M60213		CODIGO 2557
MAKROSONIC	MIT98320		2657
MAKROSONIC		RC9740	CODIGO 2794
MARSHAL	MTI1420		CODIGO 2752 / RC41
MARSHAL	MTI2020		CODIGO 2752 / RC41
MARSHALL	K3932		2481
MASUDA	K6913		2471
MECOA	P1401MN	IGUAL AL RC235 KOTRON	CODIGO 2823
MECOA			2471
MEGASTAR		PARECIDO A 2833	CODIGO 2833
METZ	DTH1444FS		

MICROSONIC	29 ADC		POSIBLE 2751
MICROSONIC	DTH1444FS		CODIGO 2625 / 21F29 / RM20
MICROSONIC	DTH1444FS		2644
MICROSONIC	DTH2044FS		CODIGO 2625 / 21F29 / RM20
MICROSONIC	M2100		2625
MICROSONIC	P1402MN		CODIGO 2823 / WINCO
MICROSONIC	T20AW		2651
MISAWA	M2000	SD-SISTEM	CODIGO 2651 / RC55 / SD SYSTEM
MISAWA	M2000		CODIGO 2554 / RM7A
MISAWA	M2000		2657
MISAWA	M2100	SD-SISTEM	CODIGO 2651 / RC55 / SD SYSTEM
MISAWA	M2100		2657
MITSAWA	M1400		2657
MITSAWA	M2000		2554
MITSUBISHI	TC-1440 NR		2470
MOVITEC		POSIBLE = GOLDMUNT	
MUSTANG	2004/5	FORMA ORIG CODIGO 3129	CODIGO 2657 / RM7A
MUSTANG	2004/5	OTRO MODELO	CODIGO 2752 / RC41
NATIONAL	TC1410NR		CODIGO 2431
NATIONAL	TC-2110 NR		2431
NATIONAL	TC2110NR		CODIGO 2431
NEKA	21 "	REMOTO PLACA TV UNIVERSAL	CODIGO 2980 / CHASIS TV UNIV
NEWTECH			2554
NISATO	NCT-1444		2431
NISATO	NCT-2044		2627
NISATO	NCT-2077		2627
NISATO	NI 2010M		CODIGO 2752 / RC41
NISATO	NI 2900ST		CODIGO 2666 / AC2006
NISATO	NI 2901ST		CODIGO 2752 / RC41
NISATO	NST1477	RC202	CODIGO 2725 / CCE RC72
NISATO	NST2077	RC202	CODIGO 2725 / CCE RC72
NISATO	NTC1444	29CH	CODIGO 2627 / RC1408
NISATO	NTC2044	29CH	CODIGO 2627 / RC1408
NISATO	TVZ2001M 20"		2725
NISATO	TVZ2101F 21"		3185
NOBLEX	602		3185
NOBLEX	609		2475
NOBLEX	14TC605	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
NOBLEX	14TC612		CODIGO 2657 / RM7A
NOBLEX	14TC612G		2435
NOBLEX	14TC612M		2481
NOBLEX	14TC616		CODIGO 2657 / RM7A
NOBLEX	14TC616	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
NOBLEX	14TC616		2481
NOBLEX	14TC627		2475
NOBLEX	14TC628		CODIGO 2665 FORMA ORIGINAL
NOBLEX	14TC628		2481
NOBLEX	14TC632	CODIGO 2645 FORM ORIG	CODIGO 2645 / RC41
NOBLEX	14TC632		2665
NOBLEX	14TC636	JXMMA	CODIGO 2777 / JXMFT
NOBLEX	14TC639	JXMMA	CODIGO 2777 / JXMFT
NOBLEX	14TC639C		2645
NOBLEX	14TC659	JXMMA	CODIGO 2777 / JXMFT
NOBLEX	14TC669 14"		2777
NOBLEX	16TC601		3185

NOBLEX	16TC675		CODIGO 2624 / FS 222 / MK6A
NOBLEX	16TC675		2557
NOBLEX	16TC687M		2624
NOBLEX	16TC697		2667
NOBLEX	16TC698	NOBLEX SIN VIDEO	CODIGO 2469 / RC0402
NOBLEX	16TC698		2667
NOBLEX	20CN655		2469
NOBLEX	20RC620		2886
NOBLEX	20TC601	NOBLEX SIN VIDEO	CODIGO 2469 / RC0402
NOBLEX	20TC601		2657
NOBLEX	20TC602	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
NOBLEX	20TC602		2469
NOBLEX	20TC603		CODIGO 2657 / RM7A
NOBLEX	20TC603F		CODIGO 2657 / RM7A
NOBLEX	20TC604		2990/2657
NOBLEX	20TC605		2475
NOBLEX	20TC607	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
NOBLEX	20TC609		2475
NOBLEX	20TC612	RD3410	CODIGO 2657 / RM7A
NOBLEX	20TC612		2653
NOBLEX	20TC612G		CODIGO 2778 / RC41
NOBLEX	20TC613	CODIGO 3102 FORM ORIG	CODIGO 2657 / RM7A
NOBLEX	20TC613G		CODIGO 2778 / RC41
NOBLEX	20TC613G		2657
NOBLEX	20TC615	FORMA ORIGINAL	CODIGO 2781 / RC 105
NOBLEX	20TC615		CODIGO 2435 / TECLA AMARILLA
NOBLEX	20TC615		2475
NOBLEX	20TC617		CODIGO 2781 / RC 105
NOBLEX	20TC618	FORMA ORIGINAL	CODIGO 2781 / RC 105
NOBLEX	20TC620	FORMA ORIGINAL	CODIGO 2781 / RC 105
NOBLEX	20TC621		CODIGO 2657 / RM7A
NOBLEX	20TC621		2781
NOBLEX	20TC621G		CODIGO 2778 / RC41
NOBLEX	20TC627		CODIGO 2665 FORMA ORIGINAL
NOBLEX	20TC627		2481
NOBLEX	20TC628		CODIGO 2665 FORMA ORIGINAL
NOBLEX	20TC629		2648
NOBLEX	20TC631	CODIGO 2645 ORIGINAL	CODIGO 2645 / RC41
NOBLEX	20TC633	CODIGO 2645 ORIGINAL	CODIGO 2645 / RC41
NOBLEX	20TC633		2629
NOBLEX	20TC637	CODIGO 2645 ORIGINAL	CODIGO 2645 / RC41
NOBLEX	20TC640		2645
NOBLEX	20TC640	1AV0U1B2220C JXMMA	CODIGO 2777 / JXMFT
NOBLEX	20TC640C		2559
NOBLEX	20TC645	1AV0U1B2220C JXMMA	CODIGO 2777 / JXMFT
NOBLEX	20TC645		2559
NOBLEX	20TC645C		2777
NOBLEX	20TC646	1AV0U1B2220C JXMMA	CODIGO 2777 / JXMFT
NOBLEX	20TC646		2559
NOBLEX	20TC646C		2481
NOBLEX	20TC650		2559
NOBLEX	20TC650V	13CH	CODIGO 2629
NOBLEX	20TC655		CODIGO 2886
NOBLEX	20TC655		2624
NOBLEX	20TC660	JXMMA	CODIGO 2777 / JXMFT

NOBLEX	20TC660		2886
NOBLEX	20TC661	JXMMA	CODIGO 2785 / JXMFT
NOBLEX	20TC662	JXMMA	CODIGO 2785 / JXMFT
NOBLEX	20TC662		2777
NOBLEX	20TC670		2560/2777
NOBLEX	20TC671	13 CH	CODIGO 2886
NOBLEX	20TC671		3185
NOBLEX	20TC674	16CH	CODIGO 2750
NOBLEX	20TC674		2886
NOBLEX	20TC676	BDCL	CODIGO 2624 / FS 222 / MK6A
NOBLEX	20TC676		2750
NOBLEX	20TC687		CODIGO 2667 / RC0422
NOBLEX	20TC687		2624
NOBLEX	20TC688M		CODIGO 2667 / RC0422
NOBLEX	20TC693		CODIGO 2667 / RC0422
NOBLEX	20TC693M		2667
NOBLEX	20TC697	NOBLEX SIN VIDEO	CODIGO 2469 / RC0402
NOBLEX	20TC697		2667
NOBLEX	20TC697C	NOBLEX SIN VIDEO	CODIGO 2469 / RC0402
NOBLEX	20TC697D	REMOTO CON VIDEO	CODIGO 2475 / RC 105-2024
NOBLEX	20TC698		2475
NOBLEX	21TC602	REMOTO CON VIDEO	CODIGO 2475 / RC 105-2024
NOBLEX	21TC602		2792
NOBLEX	21TC604	REMOTO CON VIDEO	CODIGO 2475 / RC 105-2024
NOBLEX	21TC612G		2475
NOBLEX	21TC617		2481
NOBLEX	21TC618	FORMA ORIGINAL	CODIGO 2781 / RC 105
NOBLEX	21TC621	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
NOBLEX	21TC621G	CODIGO 2645 FORM ORIG	CODIGO 2645 / RC41
NOBLEX	21TC621G		2781
NOBLEX	21TC631		2481
NOBLEX	21TC632		2645
NOBLEX	21TC633		2645
NOBLEX	21TC637		2645
NOBLEX	21TC647	1AV0U1B2220C JXMMA	CODIGO 2777 / JXMFT
NOBLEX	21TC647		2645
NOBLEX	21TC657	1AV0U1B2220C JXMMA	CODIGO 2777 / JXMFT
NOBLEX	21TC657X		2777
NOBLEX	21TC663 F	JXMFT	CODIGO 2785 / JXMFT
NOBLEX	21TC671 F	JXMFT	CODIGO 2785 / JXMFT
NOBLEX	21TC671F		2777
NOBLEX	21TC672 F	JXMFT	CODIGO 2785 / JXMFT
NOBLEX	21TC674		2785
NOBLEX	21TC681	16 CH	CODIGO 2750
NOBLEX	221TC657		2785
NOBLEX	25TC6223		2777
NOBLEX	25TC623	CODIGO 2824 FORM ORIG	CODIGO 2824 / RC 105 / CODIGO2781
NOBLEX	25TC623		2657
NOBLEX	27TC643	1AV0U1B2220C JXMMA	CODIGO 2777 / JXMFT
NOBLEX	27TC643		2781
NOBLEX	29TC614	CODIGO 2824 FORM ORIG	CODIGO 2824 / RC 105
NOBLEX	29TC614		2777
NOBLEX	29TC629		CODIGO 2972
NOBLEX	29TC629		2781
NOBLEX	29TC642	LARGO CON TAPA	CODIGO 2751 / RD3500

NOBLEX	29TC649	LARGO CON TAPA	CODIGO 2777 / JXMFT
NOBLEX	29TC649		2475
NOBLEX	29TC654F		CODIGO 2751 / RD3500
NOBLEX	29TC654F		2777
NOBLEX	29TC658		CODIGO 2785 / JXMFT
NOBLEX	29TC665X		CODIGO 2785 / JXMFT
NOBLEX	29TC668F		CODIGO 2785 / JXMFT
NOBLEX	29TC675		CODIGO 2777 / JXMGR
NOBLEX	29TC675		2553
NOBLEX	29TC680U		CODIGO 2777
NOBLEX	29TC681F		CODIGO 3530/ JXMFT
NOBLEX	29TC699C	ORIG LARGO CON TAPA/CALCULADORA	CODIGO 2838
NOBLEX	29TC699C		2785
NOBLEX	29TC699M	ORIG LARGO CON TAPA/CALCULADORA	CODIGO 2838
NOBLEX	32LC821F		2838
NOBLEX	617(M)		3558
NOBLEX	C20LB18S		2653
NOBLEX	CT620		2560
NOBLEX	TC687		2657
NOBLEX	TC693		2667
NOBLEX	TC698		2667
OLIMPIC	14TYC	RC9740	CODIGO 2657 / RM7A
OLIMPIC	20AWC		CODIGO 2657 / RM7A
OLIMPIC	20UOC	RC9740	CODIGO 2794
OLIMPIC	20UYC		CODIGO 2657 / RM7A
OLIMPIC	20VYC		CODIGO 2657 / RM7A
OLIMPIC	DCT2001M		CODIGO 2657 / RM7A
OLIMPIC	DTH2047	TECLA ROJA 29 CH	CODIGO 2627 / RC1408
OLIMPIC	LYF21		CODIGO 2776
OLIMPIC	XT7103		CODIGO 2551 / 27T08
OLITE	NOHAY MODELO	REMOTO CHASIS TV	CODIGO 2980 / CODIGO 2754
OLYMPIC	14TYC		2481
OLYMPIC	14VYC		2738
OLYMPIC	20AWC		2657
OLYMPIC	20VYC		2657
OLYMPIC	DTH-2047		2738
OLYMPIC	PC6770J		2627
OLYMPIC	RC6770J		2554
OLYMPIC	XT3751		2738
OLYMPIC	XT7103		2627
ONWA	CT1410		2822
ONWA			2624
ONWA	K9115		ONWA
ORIENT	OT2010	VERSION II	CODIGO 2661 / FS 222
ORIENT	OT2010		2471
ORIENT	OT2010R	VERSION III	CODIGO 2657 / RM7A
ORIENT	OT2010R		2624
ORIENT	OT2910		CODIGO 2657 / RM7A
ORIENT	OT2910		2624
PANASONIC	29A11A		2657
PANASONIC	29A9A		CODIGO 2430
PANASONIC	EUR501301		2462
PANASONIC	EUR50707		2429
PANASONIC	EUR67862		2463
PANASONIC	LCD3220		2462

PANASONIC	TC2007		2431
PANASONIC	TC2050NR		CODIGO 2431
PANASONIC	TC2050NR		2429
PANASONIC	TC-20A12		CODIGO 2462
PANASONIC	TC-20C7A		CODIGO 2462
PANASONIC	TC20G9A		2431
PANASONIC	TC-20G9A		CODIGO 2430
PANASONIC	TC-20KL03P		CODIGO 2462
PANASONIC	TC-20KL04A		CODIGO 2462
PANASONIC	TC20L3L		2463
PANASONIC	TC2140		2430
PANASONIC	TC2140NR		CODIGO 2431
PANASONIC	TC2140NR		2429
PANASONIC	TC29FS30LA		2431
PANASONIC	TC-29FX30/32LA		CODIGO 2981
PANASONIC	TC29G9A		2981
PANASONIC	TC29KL03A		2463
PANASONIC	TC-29KL03A		CODIGO 2462
PANASONIC	TKB2968		2462
PANATRONIC	COLOUR TV RECEIVER		2644
PANATRONIC	DPF1446		2642
PANATRONIC	DPF2046F		2578
PANAVOX	1357		CODIGO 2648 / RC18147
PANAVOX	1357		2667
PANAVOX	1467		2471
PANAVOX	2037		2627
PANAVOX	2057	29CH	CODIGO 2627 / RC1408
PANAVOX	2057		CODIGO 2648 / RC18147
PANAVOX	2057		2471
PANAVOX	2067		CODIGO 2657 / RM7A
PANAVOX	14HAC		CODIGO 2657 / RM7A
PANAVOX	2004RS		2648
PANAVOX	RM105		2644
PANORAMIC	32-CANALES		CODIGO 2471
PANORAMIC	PA2988		2657
PANORAMIC	TKB2968		3185
PANORAMIC	TVP1405AM		CODIGO 2785 / JXMFT
PANORAMIC	TVP1408M		2642
PANORAMIC	TVP-1423		CODIGO 2725 / CCE RC72
PANORAMIC	TVP-2013		CODIGO 2725 / CCE RC72
PANORAMIC	TVP-2014		CODIGO 2725 / CCE RC72
PANORAMIC	TVP2015AD		CODIGO 2785 / JXMFT
PANORAMIC	TVP2108S		3185
PANORAMIC	TVP2118F		3185
PANORAMIC	TVP2905AS		CODIGO 2785 / JXMFT
PANORAMIC	TVP2915FX		CODIGO 2785 / JXMFT
PANORAMIC	TVP2925SX		CODIGO 2785 / JXMFT
PAXAN	14 O 20 PULGADAS		2642
PAXONIC	TECLA 32CH		2648
PEABODY	P1469		CODIGO 2648 / RC18147
PEABODY	P1469		2471
PEABODY	P2069		CODIGO 2648 / RC18147
PECONIC			2648
PHILCO	14AV49	TECLA BLANCA	CODIGO 2648 / RC18147
PHILCO	14B19RC		2648

PHILCO	14B29RC		CODIGO 2627 / RC1408
PHILCO	14BP8		2648
PHILCO	14C28		2444
PHILCO	14C88RC		CODIGO2955
PHILCO	14C98AC	29CH	CODIGO 2627 / RC1408
PHILCO	14C98AC		2667
PHILCO	14C98RC		2627
PHILCO	14C98-RC		CODIGO 2667 / RC0422
PHILCO	14FC49	59CH	CODIGO 2551 / 27T08
PHILCO	14FC49		2667
PHILCO	14HR9		2551
PHILCO	14MP8	SONRISA	CODIGO 2444 / RC18147
PHILCO	14T29RC	59CH	CODIGO 2551 / 27T08
PHILCO	14T29RC		2444
PHILCO	14V1		2551
PHILCO	14V4		2449
PHILCO	14V6		2449
PHILCO	14V7		2449
PHILCO	14VI		2449
PHILCO	15M78RC	NEC 16 CANALES	CODIGO 2955
PHILCO	20/21SR8		2449
PHILCO	20AV43		2444
PHILCO	20AV49	TECLA BLANCA	CODIGO 2648 / RC18147
PHILCO	20B19RC	29CH	CODIGO 2627 / RC1408
PHILCO	20B19RC		2648
PHILCO	20BP8	RC18147 AZUL	CODIGO 2832 / RC18147
PHILCO	20BP8		2627
PHILCO	20C58		2444
PHILCO	20C80		2897
PHILCO	20C82		2897
PHILCO	20C88ST		2897
PHILCO	20C98-RC		CODIGO 2667 / RC0422
PHILCO	20CL49		CODIGO 2648 / RC18147
PHILCO	20CL49		2557
PHILCO	20D49	INTELIGENTE	CODIGO 2625 / 21F29 / RM20
PHILCO	20D49		2648
PHILCO	20FC19RC		2644
PHILCO	20FC49	59CH	CODIGO 2551 / 27T08
PHILCO	20HR9	TECLA BLANCA	CODIGO 2648 / RC18147
PHILCO	20HR9		2551
PHILCO	20MP8	SONRISA	CODIGO 2444 / RC18147
PHILCO	20MP8		2648
PHILCO	20MS6		CODIGO 2648 / RC18147
PHILCO	20MS6		2444
PHILCO	20SR8		2649-2648
PHILCO	20SR-B-ST-CR		2449/2450
PHILCO	20T19	59 CH	CODIGO 2551 / 27T08
PHILCO	20T19RC		2445
PHILCO	20T49-RC		CODIGO 2648 / RC18147
PHILCO	20U1	CHICO TECLAS CELESTES	CODIGO 2450 / RC18147
PHILCO	20V1		CODIGO 2648 / RC18147
PHILCO	20V1		2551
PHILCO	20V2		2648
PHILCO	20V49		2449
PHILCO	20V4E		CODIGO 2648 / RC18147

PHILCO	20V7		2648
PHILCO	20VI		2449
PHILCO	20VP8	DAEWOO	CODIGO 2648 / RC18147
PHILCO	21AV49	TECLA BLANCA	CODIGO 2648 / RC18147
PHILCO	21AV49		2449
PHILCO	21CD8		2648
PHILCO	21F29	INTELIGENTE CORTO	CODIGO 2625 / 21F29 / RM20
PHILCO	21F29		2444
PHILCO	21F29RC	INTELIGENTE CORTO	CODIGO 2625 / 21F29 / RM20
PHILCO	21GP8		2625
PHILCO	21M49	INTELIG. LARGO	CODIGO 2648 / RC18147
PHILCO	21M57ST	TECLA BLANCA	CODIGO 2648 / RC18147
PHILCO	21M78RC		2648
PHILCO	21M96		2869
PHILCO	21MS6	TECLA BLANCA	CODIGO 2648 / RC18147
PHILCO	21MS7		2648
PHILCO	21SR8	R38T01	CODIGO 2450 / RC18147
PHILCO	21SR8ST		2648
PHILCO	21T19		2444
PHILCO	29 NUEVO		2551
PHILCO	29CL49	AUTOSEARCH	CODIGO 2648 / RC18147
PHILCO	29M39		CODIGO 2648 / RC18147
PHILCO	29M39RC		2648
PHILCO	29M49		CODIGO 2648 / RC18147
PHILCO	29MB9		2625 o 2648
PHILCO	29MS7	SONRISA	CODIGO 2444 / RC18147
PHILCO	29MS7		2648
PHILCO	29P8		CODIGO 2648 / RC18147
PHILCO	29SR8		2444
PHILCO	BP8		2648
PHILCO	MP8		2648
PHILCO	MS6		2444
PHILCO	MS7		2648
PHILCO	MS7 29"		2551
PHILCO	ORIENT		2445
PHILCO	PD2015		CODIGO 2785 / JXMFT
PHILCO	PF2107		CODIGO 3185
PHILCO	PF2107		2657
PHILCO	PF2127		3185
PHILCO	PF2175		CODIGO 2785 / JXMFT
PHILCO	PF2198		3185
PHILCO	PF2198E	PARECE Q ES 2751	CODIGO 3523
PHILCO	PF2907		CODIGO 2785 / JXMFT
PHILCO	PF2916		CODIGO 2785 / JXMFT
PHILCO	PF2975		CODIGO 2785 / JXMFT
PHILCO	PF2998		3182
PHILCO	PF2998E	PARECE Q ES 2751	CODIGO 2872
PHILCO	PF2998E		3182
PHILCO	PFS2108SLIM		CODIGO 3185
PHILCO	PH20V5		3505
PHILCO	PH21ST		CODIGO 2782 / RC41
PHILCO	PH21ST		2449/2450
PHILCO	PHT21D4		CODIGO 2648 / RC18147
PHILCO	PHT21D4		2481
PHILCO	PHT29M2		2648

PHILCO	PH-T29M2		CODIGO 2648 / RC18147
PHILCO	PL3219 LCD		CODIGO 3584
PHILCO	PLD-2412FT		3589
PHILCO	PM1408		2648
PHILCO	PM1414		CODIGO 2785 / JXMFT
PHILCO	PM1424		CODIGO 2785 / JXMFT
PHILCO	PM2014		CODIGO 2785 / JXMFT
PHILCO	PS2114		CODIGO 2785 / JXMFT
PHILCO	PS2117		3185
PHILCO	PS2914		CODIGO 2785 / JXMFT
PHILCO	ST8ST		3185
PHILCO	T21D4E		2648
PHILCO	TS4120		CODIGO 2648 / RC18147
PHILCO	TV14V1		2648
PHILCO	TV14V4		2449/2450
PHILCO	TV14V6		2449/2450
PHILCO	TV14V6V		2449/2450
PHILCO	TV14V7		2449/2450
PHILCO	TV14VU1		2449/2450
PHILCO	TV20V1		2449/2450
PHILCO	TV20V2		2449/2450
PHILCO	TV20V4		2449/2450
PHILCO	TV20V7		2449/2450
PHILCO	TV20VU1		2449/2450
PHILIPS	20,99843994		2655
PHILIPS	2381		2454
PHILIPS	6401		2449/2450
PHILIPS	6401		2578
PHILIPS	6410		2655
PHILIPS	14CN4415	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14CN4415		2655
PHILIPS	14CN4415/77S		2655
PHILIPS	14CN4416	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14CN4417	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14CN4417		2655
PHILIPS	14CN4418	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14CN4418		2655
PHILIPS	14CT6005		2655
PHILIPS	14CT6401		2698
PHILIPS	14CT6405		2698
PHILIPS	14CT76005		2698
PHILIPS	14GL1310	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14GL1310		2655
PHILIPS	14GL1317	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14GL1318	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14GL1410	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14GL1412	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14GL1430	TRENDSET	CODIGO 2698 / RC105
PHILIPS	14GR1034		CODIGO 2436 / RC7802
PHILIPS	14GR1220	FORMA ORIGINAL RC6006	CODIGO 2436 / RC7802
PHILIPS	14GR1220		2698
PHILIPS	14GR1228	FORMA ORIGINAL RC6006	CODIGO 2436 / RC7802
PHILIPS	14GR1228		2698
PHILIPS	14GR1234	FORMA ORIGINAL RC6006	CODIGO 2436 / RC7802
PHILIPS	14GR1234		2698

PHILIPS	14GR1236	FORMA ORIGINAL RC6006	CODIGO 2436 / RC7802
PHILIPS	14GR1236		2698
PHILIPS	14GR1336		2698
PHILIPS	14GR1366	FORMA ORIGINAL RC6006	CODIGO 2436 / RC7802
PHILIPS	14GX1510	FORMA ORIGINAL RC7802	CODIGO 2436 / RC7802
PHILIPS	14GX1510		2698
PHILIPS	14GX1515		2436
PHILIPS	14GX1810	FORMA ORIGINAL RC7802	CODIGO 2436 / RC7802
PHILIPS	14GX1810		2437
PHILIPS	14GX8510	FORMA ORIGINAL RC7817	CODIGO 2951 / RC7812
PHILIPS	14GX8510		2436
PHILIPS	14GX8518	FORMA ORIGINAL RC7817	CODIGO 2951 / RC7812
PHILIPS	14GX8518		2438
PHILIPS	14GXC1815		2436
PHILIPS	14PT138A/77B		2437
PHILIPS	14PT148A		2951
PHILIPS	14PT214		CODIGO 2578 / MUJER
PHILIPS	14PT214		2951
PHILIPS	14PT314		2578
PHILIPS	14PT314B		2578
PHILIPS	14PT318A		2578
PHILIPS	14PT3331		2578
PHILIPS	14PT4131		CODIGO 2884
PHILIPS	14PT4131/77R		2454
PHILIPS	14PT4137/77		2884
PHILIPS	14PT414		3503
PHILIPS	14PT418A		2578
PHILIPS	14PT514		2578
PHILIPS	14PT616		2578
PHILIPS	14PT618A		2578
PHILIPS	14TC6401		CODIGO 2698 / RC105
PHILIPS	14TC6401		2884
PHILIPS	14TC6405		CODIGO 2698 / RC105
PHILIPS	15PF5120		2698
PHILIPS	17PF8946		2964
PHILIPS	19PFL3403/77		3539
PHILIPS	20C98RC		M1
PHILIPS	20CN4465		CODIGO 2698 / RC105
PHILIPS	20CN4465		2551
PHILIPS	20CN4465/77Z		2698
PHILIPS	20CN4466		CODIGO 2698 / RC105
PHILIPS	20CT6400		2698
PHILIPS	20CT6455/77T		2655
PHILIPS	20CT6485		2698
PHILIPS	20CT6555		2698
PHILIPS	20GL1040		CODIGO 2698 / RC105
PHILIPS	20GL1340		CODIGO 2698 / RC105
PHILIPS	20GL1340/B/M		2698
PHILIPS	20GR1055		CODIGO 2436 / RC7802
PHILIPS	20GR1055		2698
PHILIPS	20GR1355	RC7802	CODIGO 2436 / RC7802
PHILIPS	20GR1355		2655
PHILIPS	20GR1356	FORMA ORIGINAL RC6006	CODIGO 2436 / RC7802
PHILIPS	20GR1356		2698
PHILIPS	20GR1366	RC7802	CODIGO 2436 / RC7802

PHILIPS	20GR1366		2698
PHILIPS	20GX1550	RC7843	CODIGO 2437 / RC7843
PHILIPS	20GX1550		2698
PHILIPS	20GX1555	RC7843	CODIGO 2437 / RC7843
PHILIPS	20GX1555		2436
PHILIPS	20GX1560	RC7802	CODIGO 2436 / RC7802
PHILIPS	20GX1560		2437
PHILIPS	20GX1850	RC7802	CODIGO 2436 / RC7802
PHILIPS	20GX1855	RC7847	CODIGO 2437 / RC7843
PHILIPS	20GX1855		2436
PHILIPS	20GX5885	FORMA ORIGINAL RC6006	CODIGO 2436 / RC7802
PHILIPS	20GX8550	RC7812	CODIGO 2951 / RC7812
PHILIPS	20GX8550		2437
PHILIPS	20GX8558	RC7812	CODIGO 2951 / RC7812
PHILIPS	20PF5120		2436
PHILIPS	20PF5121		2964
PHILIPS	20PFL5122/77		M5
PHILIPS	20PFL5122/78		M5
PHILIPS	20PT138	RC7843 / RC7847	CODIGO 2437 / RC7843
PHILIPS	20PT148	RC7843 / RC7847	CODIGO 2437 / RC7843
PHILIPS	20PT148		2437
PHILIPS	20PT224B	TECLA SURF	CODIGO 2454 / BLANCO
PHILIPS	20PT224B		2653
PHILIPS	20PT238		2578
PHILIPS	20PT2381		2578
PHILIPS	20PT244		2951
PHILIPS	20PT2682/77A		CODIGO 2951 / RC7812
PHILIPS	20PT2682/77B		2578
PHILIPS	20PT2683		2436
PHILIPS	20PT2822/77B		3149
PHILIPS	20PT324		2951
PHILIPS	20PT324B	TECLA SURF	CODIGO 2454 / BLANCO
PHILIPS	20PT328A		2578
PHILIPS	20PT3331		2578
PHILIPS	20PT3331/77R		CODIGO 2884
PHILIPS	20PT424		2578
PHILIPS	20PT424B	FORMA MUJER	CODIGO 2578 / MUJER
PHILIPS	20PT428A	FORMA MUJER	CODIGO 2578 / MUJER
PHILIPS	20PT458A		2578
PHILIPS	20PT524		2578
PHILIPS	20PT524A		2578
PHILIPS	20PT528A		2578
PHILIPS	20TC6400		CODIGO 2698 / RC105
PHILIPS	20TC6400		2884
PHILIPS	20TC6455		CODIGO 2698 / RC105
PHILIPS	20TC6455		2655
PHILIPS	20TC6485		CODIGO 2698 / RC105
PHILIPS	20TC6485		2655
PHILIPS	20TC6555		CODIGO 2698 / RC105
PHILIPS	20TC6555		2655
PHILIPS	21CN4472		2655
PHILIPS	21GL1450	RC105	CODIGO 2698 / RC105
PHILIPS	21GL1450/T		2655
PHILIPS	21GL1452		2655
PHILIPS	21GR1260	RC7802	CODIGO 2436 / RC7802

PHILIPS	21GR1260		2655
PHILIPS	21GR1366	RC7802	CODIGO 2436 / RC7802
PHILIPS	21GR4699		2436
PHILIPS	21GX1560	RC7802	CODIGO 2436 / RC7802
PHILIPS	21GX1565	RC7847	CODIGO 2437 / RC7843
PHILIPS	21PT128A	RC7812	CODIGO 2951 / RC7812
PHILIPS	21PT1381		2436
PHILIPS	21PT2622ST		2460
PHILIPS	21PT263A		2578
PHILIPS	21PT263A		2951
PHILIPS	21PT2682		2653
PHILIPS	21PT2682ST		2460
PHILIPS	21PT334		2951
PHILIPS	21PT334A		CODIGO 2653 / RC7953
PHILIPS	21PT534		CODIGO 2578 / MUJER
PHILIPS	21PT534A		2578
PHILIPS	21PT538A		2578
PHILIPS	21PT5425/77		CODIGO 2884
PHILIPS	21PT5431		2884
PHILIPS	21PT5432		2884
PHILIPS	21PT5432/77		CODIGO 2884
PHILIPS	21PT5433/77		CODIGO 2884
PHILIPS	21PT622		CODIGO 2460 / PH917
PHILIPS	21PT6456		2884
PHILIPS	21PT656A		TCL
PHILIPS	21PT836A		2578
PHILIPS	21PT838A		CODIGO 2578 / MUJER
PHILIPS	21PT9467C/77		CODIGO 2884
PHILIPS	23PF5320		2884
PHILIPS	23PF8946/78		2964
PHILIPS	25GX1882	RC7843 / RC7847	CODIGO 2437 / RC7843
PHILIPS	25PT4622		2437
PHILIPS	25PT4622		2436
PHILIPS	25PT463A	RC7359/7340	CODIGO 2653 / RC7953
PHILIPS	25PT463A		2951
PHILIPS	25PT544		2653
PHILIPS	25PT544A		2578
PHILIPS	25PT548A		2578
PHILIPS	25PT5531		2884
PHILIPS	25PT5536		CODIGO 2884
PHILIPS	25PT5536/77		2578/2884
PHILIPS	25PT5541/77		2884
PHILIPS	25PT554A		2884
PHILIPS	25PT843		2578
PHILIPS	25PT848A		2578
PHILIPS	26PF5320/28		2884
PHILIPS	26PF5321/77		2964
PHILIPS	26PFL3404/77		2964
PHILIPS	26PFL5322/77		M1
PHILIPS	28CT7691		3502
PHILIPS	28MK2490	RC105	CODIGO 2655
PHILIPS	28MK2490		2655
PHILIPS	28PW6431		2655
PHILIPS	28PW6532		2884
PHILIPS	28PW778		2884

PHILIPS	29GX1890	RC7843 / RC7847	CODIGO 2437 / RC7843
PHILIPS	29GX1890		2779
PHILIPS	29GX1892		2437
PHILIPS	29PD6932		2779
PHILIPS	29PT461A	RC7359/7340	CODIGO 2653 / RC7953
PHILIPS	29PT461A		2454
PHILIPS	29PT4622		2436
PHILIPS	29PT4622/77R		2437
PHILIPS	29PT4630/77		2460
PHILIPS	29PT4631/77		2884
PHILIPS	29PT4631/77R		2884
PHILIPS	29PT4641/77		CODIGO 2884
PHILIPS	29PT544		2884
PHILIPS	29PT554		CODIGO 2578 / MUJER
PHILIPS	29PT554		2578
PHILIPS	29PT558A		2454
PHILIPS	29PT5632		2578/2884
PHILIPS	29PT5642/77		2884
PHILIPS	29PT5645/77		2884
PHILIPS	29PT6456/77		2884
PHILIPS	29PT656		2578
PHILIPS	29PT656/77R		2779
PHILIPS	29PT658A		2884
PHILIPS	29PT752 APIP		2578
PHILIPS	29PT785		2779
PHILIPS	29PT8419		2779
PHILIPS	29PT8419/77		2779
PHILIPS	29PT8422/77		2884
PHILIPS	29PT8457	ORIG BOTONES RED CON MENU EN EL MEDIO	LE DIMOS CODIGO 2964
PHILIPS	29PT8457/77		3503
PHILIPS	29PT8567C/77	ORIG BOTONES RED CON MENU EN EL MEDIO	LE DIMOS CODIGO 2964
PHILIPS	29PT8567C/77		3503
PHILIPS	29PT856A/77R		2779
PHILIPS	29PT9457	ORIG BOTONES RED CON MENU EN EL MEDIO	LE DIMOS CODIGO 2964
PHILIPS	29PT9457/77		3503
PHILIPS	29SX8879		2779
PHILIPS	32FL2884		2779
PHILIPS	32PD880A		2779
PHILIPS	32PF5320/28		2964
PHILIPS	32PF5320/78		2964
PHILIPS	32PF5321		2964
PHILIPS	32PFL5312/77		2964
PHILIPS	32PFL5322/77		3502
PHILIPS	32PFL5332/78		3502
PHILIPS	32PFL7342/77		3502
PHILIPS	32PFL7342/78		3502
PHILIPS	32PT6532		2884
PHILIPS	32PW878A/77R	DWIDE	CODIGO 2884
PHILIPS	33PFL312/78		2964
PHILIPS	33PFL7312/77		2964
PHILIPS	33PT5784/77R		2884
PHILIPS	33PT772A		2779
PHILIPS	33PT786A/77R		2779
PHILIPS	33PT978		2779
PHILIPS	34PT8419		2779

PHILIPS	37PFL5332/77	3502
PHILIPS	42PF7320/28	2964
PHILIPS	42PF7321/77	2964
PHILIPS	42PFL5332/77	3502
PHILIPS	42PFL7312/77	2964
PHILIPS	42PFL7312/78	2964
PHILIPS	42PFL7342/77	3502
PHILIPS	42PFL7342/78	3502
PHILIPS	50PT544A	2653
PHILIPS	52PFL5432/77	3502
PHILIPS	53UP72	2779
PHILIPS	GX8510	2653
PHILIPS	PT138	2653
PHILIPS	PT1381	2653
PHILIPS	PT138A	2653
PHILIPS	PT214	2653
PHILIPS	PT2381	CODIGO 2437 / RC7843
PHILIPS	PT2381	2653
PHILIPS	PT2622T	2653
PHILIPS	PT2682A	2653
PHILIPS	PT2822	2653
PHILIPS	PT3131	2437
PHILIPS	PT324	2578
PHILIPS	PT403	2653
PHILIPS	PT418	2578
PHILIPS	PT4622 25"	2653
PHILIPS	PT463	2653
PHILIPS	PT4631	CODIGO 2454
PHILIPS	PT514	2653
PHILIPS	PT519	2653
PHILIPS	PT524	2653
PHILIPS	PT529	2653
PHILIPS	PT5301RF	2653
PHILIPS	PT534	2653
PHILIPS	PT544	2653
PHILIPS	PT548	2653
PHILIPS	PT554	2653
PHILIPS	PT5632	2437
PHILIPS	PT616MYTV	2653
PHILIPS	PT752	2779
PHILIPS	PT772	2779
PHILIPS	PT785	2779
PHILIPS	RC031	2653
PHILIPS	TP138A	2653
PHILIPS	TP214	2653
PHILIPS	TP2381	2653
PHILIPS	VR355/77	2779
PHILIPS		2653
PHILIPS LCD 32"	PFL5312	CODIGO 2964
PHILIPS NUEVOS		CODIGO 3502
PHILIPS LCD 32"	32PFL3403/77	CODIGO 2964
PHILIPS NUEVOS		CODIGO 3503
PHILMORE		PLACA TV
POWER ACUSTIC		
PRECISION	1355RMS	CODIGO 2625 / 21F29

PRECISION	PTV1495RMS	RM20	CODIGO 2625 / 21F29
PRECISION	PTV2045RMS	29 CH	CODIGO 2627 / RC1408
PRESITION	PTV1345RMS		2627
PRIMMA	XT-3726	16 CH 14"	????
PROTECH	1405		2657
PROTECH	1498		2657
PROTECH	2005		2657
PROTECH	2098		2657
PROTECH	3146		
PROTECH	3745	ORIG TECLAS COLOR	CODIGO 2880 / RC 105-212
PROTECH	3746		POSIBLE RM7A
PROTECH	72965	ORIG TECLAS COLOR	CODIGO 2880 / RC 105-212
PROTECH	2004/5		CODIGO 2657 / RM7A
PROTECH	2004RA		2657
PROTECH	ACC110		2657
PROTECH	PTV1498		CODIGO 2657 / RM7A
PROTECH	PTV2098		CODIGO 2657 / RM7A
RADIOLA			
RANSER	2015	FS092	CODIGO 2641 / FS092 / 16RM
RANSER	2115	FS092	CODIGO 2641 / FS092 / 16RM
RANSER	218T		2624
RANSER	2580ST		2624
RANSER			CODIGO 5155
RANSER	R1415		2641
RANSER	R2015		2641
RANSER	R2060		2554
RANSER	R2080		CODIGO 2624 / FS 222 / MK6A
RANSER	R2180		CODIGO 2624 / FS 222 / MK6A
RANSER	RE2215		2657
RANSER	RS1480		CODIGO 2624 / FS 222 / MK6A
RANSER	RS2080		CODIGO 2624 / FS 222 / MK6A
RANSER	RS2180		CODIGO 2624 / FS 222 / MK6A
RANSER	RS2180		2773
RANSER	TV-RA-29PF		CODIGO 3155
ranser			CODIGO 2980 / PLACA TV
RAYSONIC	2080		2896
RAYSONIC	27000		2689
RAYSONIC	29520		2689
RAYSONIC	29521		2689
RAYSONIC	33683		2689
RAYSONIC	33684		2689
RAYSONIC	37683		2689
RAYSONIC	37684		2689
RAYSONIC	2000 1		2689
RAYSONIC	CRK64A1		2555
RAYSONIC	K3915		2471
RAYSONIC	RA2150		2555
RAYSONIC	RAR1410		2555
RAYSONIC	RAR1480		2555
RAYSONIC	RAR2010		2555
RAYSONIC	RAR2080B		2555
RAYSONIC	RAR2086B		2449
RAYSONIC	RAR2090		2555
RAYSONIC	RAR2108 SL		2736
RAYSONIC	RAR2180B		2555

RAYSONIC	RAR2190		2555
RAYSONIC	RAR2980B		2555
RAYSONIC	RAR2990		2555
RAYSONIC	RCA2700		2689
RAYSONIC	RCA29520/1		2689
RAYSONIC	RCA33683		2689
RAYSONIC	RCA37683/4		2689
RAYSONIC	RCK6 4A1		2555
RCA	33683		CODIGO 2689 / RCA-III
RCA	37684		CODIGO 2689 / RCA-III
RCA	RAR1410		CODIGO 2555 / GE BLANCO MT
RCA	RAR1480	ORIGINAL CODIGO 2986	CODIGO 2736 (RCA CHICO)
RCA	RAR2010		CODIGO 2555 / GE BLANCO MT
RCA	RAR2050		CODIGO 2555 / GE BLANCO MT
RCA	RAR2070		CODIGO 2555 / GE BLANCO MT
RCA	RAR2080B	ORIGINAL CODIGO 2986	CODIGO 2736 (RCA CHICO)
RCA	RAR2090		CODIGO2736
RCA	RAR2108USL		CODIGO 3556
RCA	RAR2108USL	ORIGINAL COMO CODIGO 2879 PERO NEGRO	CODIGO 2736 (RCA CHICO)
RCA	RAR2110		CODIGO 2555 / GE BLANCO MT
RCA	RAR2180		CODIGO 2736 (RCA CHICO)
RCA	RAR2190		CODIGO 2736 (RCA CHICO)
RCA	RAR2908SL		CODIGO 3556
RCA	RAR2908SL	ORIGINAL COMO CODIGO 2879 PERO NEGRO	CODIGO 2736 (RCA CHICO)
RCA	RAR2990		CODIGO 2736 (RCA CHICO)
RCA	RARTF21NB		CODIGO 3178
RCA	TF2121S		CODIGO 3178
RCA	TF2521	PANTALLA PLANA	CODIGO 3178
RCA	TF2920	PANTALLA PLANA	CODIGO 3178
RCA	RAR2150 M		CODIGO 2555 / GE BLANCO MT
RECCO	RTV28221		2892
RECOR	4029		CODIGO 2977 / RC 105
RECOR	4029		2655
RECOR	20"		CODIGO 2977 / RC 105
RECOR	20"		2655
RECOR	CTV2502		CODIGO 2977 / RC 105
RECOR	CTV2502		2655
RECOR	CTV2902		CODIGO 2977 / RC 105
RECOR	CTV2902		2655
REGENCY	R20K		CODIGO 2657 / RM7A
REGENCY	R20K		2554
REGENCY	R211K		CODIGO 2651 / RC55 / SD SYSTEM
REPMAN	EPU39	32 CH	MA 2471 / DEWO 32 CH
ROSARIO	P1401 MN		2804
SABA	21SFL		CODIGO 3561
SAKURA	CT1493		2451
SAKURA	S2093R		2451
SAKURA	SKR 75JG21		CODIGO 2735 / RC915
SAMSON JAPAN	tecla naranja 32Ch		2471
SAMSUNG	20TOC	RC9740	CODIGO 2794
SAMSUNG	3351V		2435
SAMSUNG	5085 VB20		2435
SAMSUNG	AM2002		2667
SAMSUNG	CL15K5MN		CODIGO 2967
SAMSUNG	CL-17K10MJ		CODIGO 2967

SAMSUNG	CL-21K40MQ		CODIGO 2967/ 3118
SAMSUNG	CL-21M2		2967
SAMSUNG	CL-21M21		2967
SAMSUNG	CL-21M6		2967
SAMSUNG	CL-21T21		2967
SAMSUNG	CL-21Z43MQ		CODIGO 2967
SAMSUNG	CL-21Z50MQ	SLIM	
SAMSUNG	CL-29K40	CONFIRMA 103	POSIBLE CODIGO 3118
SAMSUNG	CL-29M16		2967
SAMSUNG	CL-29M2		2967
SAMSUNG	CL-29M21		2967
SAMSUNG	CL-29T21		2967
SAMSUNG	CL-29Z50MQ		CODIGO 2967
SAMSUNG	CL-32Z30DS		CODIGO 2967
SAMSUNG	CL-32Z40DS		CODIGO 2967
SAMSUNG	CLP-300		CODIGO 2967
SAMSUNG	CLP-300-ELS		CODIGO 2967
SAMSUNG	CN2073		2435
SAMSUNG	CN25D4 WZ		2792
SAMSUNG	CN29D4		2792
SAMSUNG	CN321M		2667
SAMSUNG	CN321Z/M	CODIGO 2667 ORIGINAL	CODIGO 2667 / RC0422
SAMSUNG	CN331		2435
SAMSUNG	CN3312Z		CODIGO 2557
SAMSUNG	CN3326Z	NOBLEX SIN VIDEO	CODIGO 2469 / RC0402
SAMSUNG	CN3326Z		2469
SAMSUNG	CN3338		2435
SAMSUNG	CN3338VB	SAMSUNG BOTON AMARILLO	CODIGO 2435
SAMSUNG	CN3338VB		2653
SAMSUNG	CN3338Z		CODIGO 2792 / 00021E
SAMSUNG	CN3338Z		2792
SAMSUNG	CN3339		CODIGO 2648 / RC18147
SAMSUNG	CN3339		2435
SAMSUNG	CN3339VB	SAMSUNG BOTON AMARILLO	CODIGO 2435
SAMSUNG	CN3339VB		2653
SAMSUNG	CN3348V		CODIGO 2435 / TECLA AMARILLA
SAMSUNG	CN3351V		CODIGO 2475 / RC 105-2024
SAMSUNG	CN3352Z	FRENTE OVAL	CODIGO 2657 / RM7A
SAMSUNG	CN3352Z		2667
SAMSUNG	CN3366		2435
SAMSUNG	CN3373		2435
SAMSUNG	CN3380		2435
SAMSUNG	CN3383		2435
SAMSUNG	CN3385VB	SAMSUNG BOTON AMARILLO	CODIGO 2435
SAMSUNG	CN3385VB		2653
SAMSUNG	CN501		2435
SAMSUNG	CN5013Z	NOBLEX SIN VIDEO	CODIGO 2469 / RC0402
SAMSUNG	CN5027Z		2557
SAMSUNG	CN5038		2792
SAMSUNG	CN5038VB	SAMSUNG BOTON AMARILLO	CODIGO 2435
SAMSUNG	CN5038Z		CODIGO 2792 / 00021E
SAMSUNG	CN5039		2435
SAMSUNG	CN5039VB	SAMSUNG BOTON AMARILLO	CODIGO 2435
SAMSUNG	CN5048V	SAMSUNG BOTON AMARILLO	CODIGO 2435
SAMSUNG	CN5051C	TV CON LLAVE SINTO Y NORMA	CODIGO 2469 / RC0402

SAMSUNG	CN5051V		CODIGO 2475 / RC 105-2024
SAMSUNG	CN5051Z		CODIGO 2469 / RC0402
SAMSUNG	CN5052Z		CODIGO 2469 / RC0402
SAMSUNG	CN5066		2435
SAMSUNG	CN5083		2435
SAMSUNG	CN5085		CODIGO 2435 / TECLA AMARILLA
SAMSUNG	CN5085		2435
SAMSUNG	CN5085BZ	ORIGINAL 00021E	CODIGO 2792 / 00021E
SAMSUNG	CN5085VB		2475
SAMSUNG	CN5372WB	ORIG COMO BOTON AMARILLO PERO MAS LARGO	CODIGO 2550
SAMSUNG	CN5372WN		2475
SAMSUNG	CN540		2667
SAMSUNG	CN540M		CODIGO 2667 / RC0422
SAMSUNG	CN565BWZ	ORIGINAL 00021E	CODIGO 2792 / 00021E
SAMSUNG	CN6230		CODIGO 2657 / RM7A
SAMSUNG	CN6230C		2557
SAMSUNG	CN6565BWZ	ORIGINAL 00021E	CODIGO 2792 / 00021E
SAMSUNG	CN656BWZ		desconocido
SAMSUNG	CN663 AWZ		2792
SAMSUNG	CN7202-WZ	ORIGINAL 00021E	CODIGO 2792 / 00021E
SAMSUNG	CN722AP		CODIGO 2792 / 00021E
SAMSUNG	CN722AP		2475
SAMSUNG	CN7230C	CALCULADORA	CODIGO 2838
SAMSUNG	CN7230C		2469
SAMSUNG	CN7230W	CALCULADORA	CODIGO 2838
SAMSUNG	CN723AP		CODIGO 2792 / 00021E
SAMSUNG	CN723AP		2475
SAMSUNG	CN765-AWZ		CODIGO 2792 / 00021E
SAMSUNG	CN765-DWZ		NO SE SABE REEMPLAZO
SAMSUNG	LN32R7IBAXIXBG		CODIGO 3118 (POSIBLE)
SAMSUNG	TC2450SX		2557
SANKEI	CT1433BR		2624
SANKEI	CT2023BR		2641
SANKEI	CT2033BR		2641
SANKEY	CT1433BR		CODIGO 2624 / FS 222 / MK6A
SANKEY	CT2033BR		CODIGO 2624 / FS 222 / MK6A
SANSEI	1414		2648
SANSEI	1446		2738
SANSEI	2014		2740
SANSEI	AC201M	29CH	CODIGO 2627 / RC1408
SANSEI	CTVG4545LS	29CH	CODIGO 2627 / RC1408
SANSEI	TS0114		CODIGO 2785 / JXMFT
SANSEI	TS0114		2559
SANSEI	TS0120		CODIGO 2785 / JXMFT
SANSEI	TS0120		2559
SANSEI	TS0120D		2559
SANSEI	TS0420		2559
SANSEI	TS0420D		2559
SANSEI	TS0427S	TV 25 A 29"	CODIGO 2559 / FXFR
SANSEI	TS1414		2559
SANSEI	TS4114		CODIGO 2785 / JXMFT
SANSEI	TS4120		CODIGO 2785 / JXMFT
SANSEI	TS4121S		CODIGO 2785 / JXMFT
SANSEI	TS4129S		CODIGO 2785 / JXMFT
SANSEI	TS4421S		CODIGO 2785 / JXMFT

SANSEI	TS5121F		CODIGO 2785 / JXMFT
SANSEI	TS6120B		CODIGO 2785 / JXMFT
SANSEI	TS6121F		CODIGO 2785 / JXMFT
SANSEI	TS6121S		CODIGO 2785 / JXMFT
SANSEI	TS6221F		CODIGO 2785 / JXMFT
SANSEI	TS6229S		CODIGO 2785 / JXMFT
SANSEI	TS7121S		3185
SANSEI	TS7221F		3185
SANSEI	TS8120M		3185
SANSEI	TSO		2559
SANSEI	TVR1312	46 CH	CODIGO 2625 / 21F29 / RM20
SANSEI	TVR1312		2644
SANSEI	TVR1414	T BLANCA	CODIGO 2648 / RC18147
SANSEI	TVR1416		CODIGO 2625 / 21F29 / RM20
SANSEI	TVR1416		2554
SANSEI	TVR1418	JXVD	CODIGO 2559 / FXFR
SANSEI	TVR2011	46 CH	CODIGO 2625 / 21F29 / RM20
SANSEI	TVR2011		2644
SANSEI	TVR2014	T BLANCA	CODIGO 2648 / RC18147
SANSEI	TVR2016		CODIGO 2625 / 21F29 / RM20
SANSEI	TVR2016		2554
SANSEI	TVR2018	JXVD	CODIGO 2559 / FXFR
SANSEI	TVR2019	JXVD	CODIGO 2559 / FXFR
SANSEI	TVR2024	IGUAL PHILCO 20MS6	CODIGO 2648 / RC18147
SANSEI	TVR2026		CODIGO 2657 / RM7A
SANSEI	TVR2026		2554
SANSEI	TVR2116	RC6145	CODIGO 2657 / RM7A
SANSEI	TVR2116		2990
SANSEI	TVR2919S	LARGO CON TAPA	CODIGO 2751 / RD3500
SAMSUNG	CN7230M		CODIGO 2469 / RC0402
SANWA	K6821	ONWA 32 CH	CODIGO 2471 / RC36B
SANWA	K6913	ONWA 32 CH	CODIGO 2471 / RC36B
SANYO	1		2459
SANYO	20LV33SE/ST	FXFR	CODIGO 2559 / FXFR
SANYO	27LW33-5ST	FXFR	CODIGO 2559 / FXFR
SANYO	27LW47	FXFR	CODIGO 2559 / FXFR
SANYO	C1421		2791
SANYO	C14L313M		CODIGO 2560 / FXFR
SANYO	C14LT13M	FXFR	CODIGO 2559 / FXFR
SANYO	C14LT13ME	FXFR	CODIGO 2559 / FXFR
SANYO	C14LT77M		2560
SANYO	C14LT83M	FXFR	CODIGO 2559 / FXFR
SANYO	C14LT84M	FXFR	CODIGO 2559 / FXFR
SANYO	C14LT84M		2560
SANYO	C14LT84ME		2560
SANYO	C14LT88M		CODIGO 2570 / JXMGR
SANYO	C20LB13CE	FXMR	CODIGO 2559 / FXFR
SANYO	C20LB13S	FXMR	CODIGO 2559 / FXFR
SANYO	C20LB14S	FXMR	CODIGO 2559 / FXFR
SANYO	C20LB14S		2560
SANYO	C20LB14SE		2560
SANYO	C20LB18S		CODIGO 2570 / JXMGR
SANYO	C20LB18S		2559
SANYO	C20LB23S	FXMR	CODIGO 2559 / FXFR
SANYO	C20LB23S / SE		2559

SANYO	C20LB23SE	FXMR	CODIGO 2559 / FXFR
SANYO	C20LB49M		2559
SANYO	C20LB87M	FXMR	CODIGO 2560 / FXFR
SANYO	C20LB88B		CODIGO 2570 / JXMGR
SANYO	C20LB93M	FXFR	CODIGO 2559 / FXFR
SANYO	C20LB94M	FXFR	CODIGO 2559 / FXFR
SANYO	C20LB94ME		2559
SANYO	C20LB98M		CODIGO 2570 / JXMGR
SANYO	C20LE90BC	FXFR	CODIGO 2559 / FXFR
SANYO	C20LE90BC		2569
SANYO	C20LE90SB	#0600	CODIGO 2569 / JXLR
SANYO	C20LE90SB		2559
SANYO	C20LV23 ME	FXFR	CODIGO 2559 / FXFR
SANYO	C20LV23M	FXFR	CODIGO 2559 / FXFR
SANYO	C20LV23MCR	FXFR	CODIGO 2559 / FXFR
SANYO	C20LV23MCR		2461
SANYO	C20LV32M		2559
SANYO	C20LV33	FXFR	CODIGO 2559 / FXFR
SANYO	C20LV33D	FXFR	CODIGO 2559 / FXFR
SANYO	C20LW33S	FXFR	CODIGO 2559 / FXFR
SANYO	C20LW33S		2559
SANYO	C21LB13SE		2560
SANYO	C21LB23S	FXMR SANYO FLUOR	CODIGO 2560 / FXFR
SANYO	C21LB23SE		2560
SANYO	C21LB24S	FXMR SANYO FLUOR	CODIGO 2560 / FXFR
SANYO	C21LB24SE		2560
SANYO	C21LB29S		CODIGO 2570 / JXMGR
SANYO	C21LB76		2570
SANYO	C21LB77		2560
SANYO	C21LB77E		2560
SANYO	C21LB90S	DIGICON	CODIGO 3156
SANYO	C21LF37	JXMFT	CODIGO 2785 / JXMFT
SANYO	C21LF41		3185
SANYO	C21LF41B		3185
SANYO	C21LM90B		2569
SANYO	C21LM90S	#0600	CODIGO 2569 / JXLR
SANYO	C21LM90S		2559
SANYO	C21LM90SB	#0600	CODIGO 2569 / JXLR
SANYO	C21LM90SB		2559
SANYO	C21LV23S	FXMR	CODIGO 2559 / FXFR
SANYO	C21TF26S	CODIGO 2787 ORIGINAL / RC83	RULO A CONFIRMAR
SANYO	C221LB23S		2559
SANYO	C22LB23S		2560
SANYO	C27LW13S		2559
SANYO	C27LW335ST		2559
SANYO	C27LW33S	FXFR	CODIGO 2559 / FXFR
SANYO	C27LW33SE		2461
SANYO	C27LW44S		2559
SANYO	C27LW44SE		2559
SANYO	C27LW47S		2559
SANYO	C27LW47SE		2559
SANYO	C27LW47SE PIP		2461
SANYO	C27LWSE/ST	FXFR	CODIGO 2559 / FXFR
SANYO	C29H93	DIGICON	CODIGO 3156
SANYO	C29LF37	FLAT	CODIGO 2785 / JXMFT

SANYO	C29LF39		2560
SANYO	C29LH43	DIGICON	CODIGO 3156
SANYO	C29LH43		2559
SANYO	C29LH93		2461
SANYO	C29LH96	FXFR	CODIGO 2559 / FXFR
SANYO	C29LK33		2559
SANYO	C29LK33/34	FXMR	CODIGO 2559 / FXFR
SANYO	C29LK34		2560
SANYO	C29LK34E		2560
SANYO	C29LK35		2559
SANYO	C29LK39S		CODIGO 2570 / JXMGR
SANYO	C29LK40S		CODIGO 2570 / JXMGR
SANYO	C29LK96E	FXMR	CODIGO 2559 / FXFR
SANYO	C33LJ13	FXBB	CODIGO 2559 / FXFR
SANYO	C33LJ26	FXBB	CODIGO 2559 / FXFR
SANYO	C33LJ35		2560
SANYO	C33LJ35E	FXBB	CODIGO 2559 / FXFR
SANYO	C33LJ39		2559
SANYO	C33LJ99	FXFR	CODIGO 2559 / FXFR
SANYO	C33LT13		3156
SANYO	CL20LM90B	#0600	CODIGO 2569 / JXLR
SANYO	CL21LM90S		2569
SANYO	CLP1421	28CH	CODIGO 2459 / RC702
SANYO	CLP1450	#0600	CODIGO 2569 / JXLR
SANYO	CLP1451	#0600	CODIGO 2569 / JXLR
SANYO	CLP2050	#0600	CODIGO 2569 / JXLR
SANYO	CLP2051	#0600	CODIGO 2569 / JXLR
SANYO	CLP2051C	FXFR	CODIGO 2559 / FXFR
SANYO	CLP2051R		2569
SANYO	CLP2120	28CH	CODIGO 2459 / RC702
SANYO	CLP2121	28CH	CODIGO 2459 / RC702
SANYO	CLP2122	DUDOSO	CODIGO 2459 / RC702
SANYO	CLP2143	4AA4U1T0064	CODIGO 2448 / 32CH
SANYO	CLP2151	#0600	CODIGO 2569 / JXLR
SANYO	CLP3022		2448
SANYO	CLP3024	#0064	CODIGO 2569 / JXLR
SANYO	CLP3024		2448
SANYO	CLP6022	4AA4U1T0064	CODIGO 2448 / 32CH
SANYO	CLP6024	4AA4U1T0064	CODIGO 2448 / 32CH
SANYO	CLP6024		2448
SANYO	CLP6029	4AA4U1T0064	CODIGO 2448 / 32CH
SANYO	CLX2800	28CH	CODIGO 2459 / RC702
SANYO	CLX2800SR	RC646	CODIGO 2893
SANYO	CPT6735		desconocido
SANYO	CPT6737		2791
SANYO	CTP3735	RC303 8 CH	NO HAY REEMP
SANYO	CTP3735		desconocido
SANYO	CTP3737	29CH	CODIGO 2791 / RC643
SANYO	CTP6730A		desconocido
SANYO	CTP6731A		2785
SANYO	CTP6735	RC303 8 CH	NO HAY REEMP
SANYO	CTP6737	RC643 29 CH	CODIGO 2791
SANYO	LB25		2559
SANYO	LH93	FXFR	CODIGO 2559 / FXFR
SANYO	LH93		2559

SANYO	LT13-ST 33	FXBB	CODIGO 2559 / FXFR
SANYO	PIP		3512
SANYO	S21LB24SE	B	CODIGO 2559 / FXFR
SANYO	S27LW44S	FXBB	CODIGO 2559 / FXFR
SANYO	SC200A		2896
SANYO	SLP1451		2569
SANYO	SLP6022		2448
SANYO	SLP6024		2569
SANYO	SLP6424		2559
SANYO LCD	42XF7		CODIGO 3558
SCHAUB LORENZ	20Z3		2624
SEIKO	TSL-211		CODIGO 2984
SERIE DORADA	13SB50 lynytron		desconocido
SERIE DORADA	14AD	FS207	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	14C82		2657
SERIE DORADA	20C1		CODIGO 2554 / RM7A
SERIE DORADA	20C1		2657
SERIE DORADA	20Z3	FS207	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	25Z3	FS207	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	29Z3	FS207	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	CNT4685B	GOLDSTAR 15 CANALES DE CODIGO	CODIGO 2577
SERIE DORADA	CNT9522	GOLDSTAR 15 CANALES DE CODIGO	CODIGO 2577
SERIE DORADA	FS207F		2624
SERIE DORADA	SD1		2651
SERIE DORADA	SD1420	FS095	CODIGO 2641 / FS092 / 16RM
SERIE DORADA	SD1423		2624
SERIE DORADA	SD1430	FS185	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SD1430		2451
SERIE DORADA	SD1440	FS185	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SD1440AD		2624
SERIE DORADA	SD14C2DP		2554
SERIE DORADA	SD14GL		2657
SERIE DORADA	SD14LG	FUZZY	CODIGO 2554 / RM7A
SERIE DORADA	SD14LG		2738
SERIE DORADA	SD14X2		2792
SERIE DORADA	SD14Z3	FS207	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SD2014	FS095	CODIGO 2641 / FS092 / 16RM
SERIE DORADA	SD2014 JUBILEE	FS095	CODIGO 2641 / FS092 / 16RM
SERIE DORADA	SD2023	FS207	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SD2030	FS185	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SD2030		2451
SERIE DORADA	SD2040	FS207	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SD20C1		2554
SERIE DORADA	SD20C2DP	RD3215G	CODIGO 2554 / RM7A
SERIE DORADA	SD20C2DP		2657
SERIE DORADA	SD20C2DPST		2554
SERIE DORADA	SD20C2DPST / 20C4		2554
SERIE DORADA	SD20C4	RD3215G	CODIGO 2554 / RM7A
SERIE DORADA	SD20C4		2657
SERIE DORADA	SD20LG	FUZZY	CODIGO 2554 / RM7A
SERIE DORADA	SD20X2	SIMIL SAMSUNG	CODIGO 2792 / 00021E
SERIE DORADA	SD2115		FS 092
SERIE DORADA	SD2130	FS092	CODIGO 2641 / FS092 / 16RM
SERIE DORADA	SD2140		2624
SERIE DORADA	SD2140 AD		2624

SERIE DORADA	SD2140ST	FS232 / 207	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SD21D1	SD-SISTEM	CODIGO 2651 / RC55 / SD SYSTEM
SERIE DORADA	SD21D10		2624
SERIE DORADA	SD21D2	SD-SISTEM	CODIGO 2651 / RC55 / SD SYSTEM
SERIE DORADA	SD21D3	SD-SISTEM	CODIGO 2651 / RC55 / SD SYSTEM
SERIE DORADA	SD21D4	SD-SISTEM	CODIGO 2651 / RC55 / SD SYSTEM
SERIE DORADA	SD21LG	FUZZY	CODIGO 2657 / RM7A
SERIE DORADA	SD2523	TECLAS TRIANG.	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SD25Z3		2624
SERIE DORADA	SD2940	105-198C	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SD2940ST		CODIGO 2657 / RM7A
SERIE DORADA	SD2940Z3		2624
SERIE DORADA	SP1420	CR646	CODIGO 2624 / FS 222 / MK6A
SERIE DORADA	SP1420		2451
SERIE DORADA		GRK34H-C22	CODIGO 3196
SHARP	2092		2688
SHARP	1480Y		2688
SHARP	19RM-1005	TELE MEXICANA	CODIGO 2858
SHARP	20A-M120		CODIGO 3104
SHARP	21ST04	100CH	CODIGO 3104
SHARP	21ST04		2833
SHARP	27J-S100		CODIGO 2858
SHARP	29FL05	KB2900	CODIGO 2642 / KB2900
SHARP	29ST06		CODIGO 2666 / AC2006
SHARP	29ST06		2642
SHARP	4520ME		2624
SHARP	C1453Y	29 CH	CODIGO 2563
SHARP	C1453Y	GRISESITO NUEVO	CODIGO 2858
SHARP	C1453Y		2622
SHARP	C1652Y	13 CH	CODIGO 2869
SHARP	C2051Y	13 CH	CODIGO 2869
SHARP	C2060Y	13 CH	CODIGO 2869
SHARP	C2070Y	13 CH	CODIGO 2869
SHARP	C2072		2554
SHARP	C2072Y	RH3411	CODIGO 2657 / RM7A
SHARP	C2082Y	29 CH	CODIGO 2563
SHARP	C2085Y	39 CH	CODIGO 2688
SHARP	C2092B		2688
SHARP	C2093Y	LARGO TECLA AZUL	CODIGO 2622 (IGUAL 3104)
SHARP	C2093Y		2688
SHARP	C2098Y	13 CH	CODIGO 2869
SHARP	C2099Y		CODIGO 2869
SHARP	C20T51	100CH	CODIGO 3104
SHARP	C2182Y	RH3411	CODIGO 2657 / RM7A
SHARP	C2182Y		2554
SHARP	C2800		2869
SHARP	C3020Y	16 CH	CODIGO 2868
SHARP	C3020Y		desconocido
SHARP	C3050K		2624
SHARP	C3520Y	16 CH	CODIGO 2868
SHARP	SH-1-2110ST		CODIGO 2666 / AC2006
SHARP	SH-1-2111ST		CODIGO 2666 / AC2006
SHARP	SH-1-2910ST		2666
SHARP	SH-1-2911FL		CODIGO 2666 / AC2006
SHARP	SH-1-2911FT		CODIGO 2666 / AC2006

SHOWA	AW2003		CODIGO 2471 / RC36B
SHOWA	AW2103		CODIGO 2471 / RC36B
SIAM	SM2001	SIMIL GRU CUC 200	CODIGO 2698 / RC105
SIAM	WINER		desconocido
SILVER CROWN	RECORD		desconocido
SILVER CROWN		COMO EL RECOR	CODIGO 2977 / RC 105
SONY	21C40		CODIGO 2472
SONY	29XTR2		2427
SONY	CVTP1402MN		desconocido
SONY	KV.21FS120	WEGA KV-21F	NOSE SABE REEMPLAZO
SONY	KV13TR28/29		2628
SONY	KV13V50		2658
SONY	KV1414		2427
SONY	KV1430R		2628
SONY	KV1440WR		2628
SONY	KV1473RWR		2427
SONY	KV1473WP		2427
SONY	KV1484AN		2427
SONY	KV14MB40A		2628
SONY	KV14MTR2		2658
SONY	KV1602M7		2427
SONY	KV1612		desconocido
SONY	KV1914		2427
SONY	KV1965R		2427
SONY	KV1967WP		2427
SONY	KV1975R		2427
SONY	KV2022		2886
SONY	KV2067AN		2427
SONY	KV2067PWP		2427
SONY	KV2067RR		2427
SONY	KV20EXR20		2427
SONY	KV20ST29		2628
SONY	KV20TR23		2628
SONY	KV20TS32		2628
SONY	KV20TS50		2658
SONY	KV20V50		2658
SONY	KV2150R		2628
SONY	KV2154AN		2427
SONY	KV2160WR		2628
SONY	KV2170RS		2628
SONY	KV-2184		CODIGO 2427
SONY	KV-2185		CODIGO 2427
SONY	KV21ATR1		2658
SONY	KV21FE12		2628
SONY	KV21FS105		2786
SONY	KV21SE40A		CODIGO 2658 / CODIGO2628
SONY	KV21SE40A		2628
SONY	KV21SE80A		2786
SONY	KV21STR2		2628
SONY	KV21XTR3		2628
SONY	KV24SE40		2658
SONY	KV27V55		2658
SONY	KV2940		2427
SONY	KV2964MT/MTT		2427
SONY	KV-29LV65A		CODIGO 2986

SONY	KV29STR9		2658
SONY	KV29V55M/C		2658
SONY	KV29VTR10		2658
SONY	KV29VTR10		2658
SONY	KV29VTR15S		2658
SONY	KV29XTR1		2427
SONY	KV29XTR9		2628
SONY	KV32TS20		desconocido
SONY	KVTS232		2658
SONY	KVTS50		2628
SONY	RM687		2427
SONY	TODOS	RMY116	CODIGO 2658 / CODIGO2628
SPECTRUM	TVR1310T		CODIGO 2823
SPICA	GN21B		CODIGO 2471 / RC36B
SPICA	NUEVO URUGUAYO	TAMBIEN MARCA KONKA	CODIGO 2755
SPICA	SE40		2628
STEELHOME	SHT202M		3185
STEELHOME	SHT212F		3185
STEELHOME	SHT213S		3185
STEELHOME	SHT292F		2559
STELL HOME	SHT200M		CODIGO 2785 / JXMFT
STELL HOME	SHT210S		CODIGO 2785 / JXMFT
STELL HOME	SHT211F		CODIGO 2785 / JXMFT
STELL HOME	SHT290F		CODIGO 2785 / JXMFT
SUBARU	CVTP1401MM		2823
SURREY	GT9320		CODIGO 2553 / DUMONT
SUZUKI	29"		CODIGO 2776
TAHOCI	THC13A	RC9740	CODIGO2794
TAKAKA	TKT-4000		
TAKAKA	TKT-933		CODIGO 2692
TAKAKA	TKT-934		CODIGO 2692
TAKUMA	21PF-21G		CODIGO 2776
TAKUMA	29PF-29G		CODIGO 2776
TALENT	1360	FB1120	CODIGO 2456 / FB1120
TALENT	9320		2471
TALENT	14/10s		desconocido
TALENT	14/15C		desconocido
TALENT	20/0509C		desconocido
TALENT	2015SP		CODIGO 2698 / RC105
TALENT	2015SP		2655
TALENT	29A1		2642
TALENT	29-C1		CODIGO 2642 / KB2900
TALENT	29FL05		2642
TALENT	B116SP		2655
TALENT	DIGIVISION 20		desconocido
TALENT	HPS1423	RC202	CODIGO 2725
TALENT	HPS1479	RC202	CODIGO 2725
TALENT	HPS2023	RC202	CODIGO 2725
TALENT	HPS2079	RC202	CODIGO 2725
TALENT	HPS2118	RC202	CODIGO 2725
TALENT	HPS3301	RC202	CODIGO 2725
TALENT	N38L		2980
TALENT	T20A		2554
TALENT	TA2109AB		2752
TALENT	TA-2131 FT		CODIGO 2666 / AC2006

TALENT	TA2931		2642
TALENT	TA-3-2131FT		CODIGO 2666 / AC2006
TALENT	TA-3-2931FT		CODIGO 2666 / AC2006
TALENT	TF29X		CODIGO 2785 / JXMFT
TALENT	TV14MX		CODIGO 2785 / JXMFT
TALENT	TV20BX		CODIGO 2785 / JXMFT
TALENT	TV21SX		CODIGO 2785 / JXMFT
TALENT	TV29SX		CODIGO 2785 / JXMFT
TALENT	TVP9215	32 CH	CODIGO 2471 / RC36B
TALENT	TVP9215		2553
TALENT	TVP9220	T. NARANJA 125 CH	CODIGO 2553 / RC181
TALENT	TVP9320		CODIGO 2553 / RC181
TALENT	TVP9420	RC6145	CODIGO 2657 / RM7A
TALENT	TVP9420		2990
TALENT	TVP9421		2657
TALENT	TVP9425	RE2215 C/MTS	CODIGO 2657 / RM7A
TALENT	TVP9429		CODIGO 2657 / RM7A
TALENT	TVP9520		CODIGO 2782 / RC41
TALENT	TVP9629		CODIGO 2838
TALENT	TVP9820	RE2215B	CODIGO 2657 / RM7A
TALENT	TVP9825		CODIGO 2553 / DUMONT
TALENT	TVP9829		2553
TALENT	TVP-9920		2481
TALENT	TVP-9920		CODIGO 2782 / RC41
TALENT	TVTF21X		CODIGO 2785 / JXMFT
TALENT	Z2990		CODIGO2752
TALENT	Z2990		CODIGO 2752
TALENT	Z2990ST		2752
TAMASHI	XT1961		2553
TAMASHI	XT-1961 D		CODIGO 2652
TCL	2127	CODIGO 2787 ORIGINAL / RC83	CODIGO 2892 / RC135
TCL	21A71	CODIGO 2787 ORIGINAL / RC83	CODIGO 2892 / RC135
TCL	21E11A		CODIGO 2892 / RC135
TCL	21E12		2736
TCL	21F5USLIM		CODIGO 3566
TCL	29F5SLIM		CODIGO 3566
TCL	CTV21276		
TCL	MODELO 21E14		
TCL	TCL21E11		
TCL LCD	26M91HD		CODIGO 3572
TELEFUNKEN	1360		2456
TELEFUNKEN	1370		CODIGO 2557
TELEFUNKEN	1370		2793
TELEFUNKEN	1390	FB1120	CODIGO 2456 / FB1120
TELEFUNKEN	1390		2793
TELEFUNKEN	1395	FB1120	CODIGO 2456 / FB1120
TELEFUNKEN	1430	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
TELEFUNKEN	1430		2469
TELEFUNKEN	1560		2793
TELEFUNKEN	1590		2793
TELEFUNKEN	2036	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
TELEFUNKEN	2335		2793
TELEFUNKEN	3296		2793
TELEFUNKEN	1350K		desconocido
TELEFUNKEN	2004RS		2481

TELEFUNKEN	2121N	FB1120	CODIGO 2456 / FB1120
TELEFUNKEN	212TN		2456
TELEFUNKEN	29 PULGADAS		2469
TELEFUNKEN	BISONIC 16/20/27		2793
TELEFUNKEN	BISONIC 21		2793
TELEFUNKEN	MP141N		CODIGO 2469 / RC0402
TELEFUNKEN	MP141N		CODIGO 2657 / RM7A
TELEFUNKEN	MP212		2456
TELEFUNKEN	MP212N		CODIGO 2456 / FB1120
TELEFUNKEN	MP213N	FB1120	CODIGO 2456 / FB1120
TELEFUNKEN	MP292		2557
TELEFUNKEN	MP512		2667
TELEFUNKEN	TFK1340	ORIGINAL FRENTE DE CHAPA PLATEADO	
TELEFUNKEN	TK 2985		CODIGO 2624 / FS 222 / MK6A
TELEFUNKEN	TK1429		CODIGO 2833
TELEFUNKEN	TK1436	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
TELEFUNKEN	TK1469		CODIGO 2624 / FS 222 / MK6A
TELEFUNKEN	TK1499		2792
TELEFUNKEN	TK2009ST		CODIGO 2792 / 00021E
TELEFUNKEN	TK2028	FUZZY	CODIGO 2657 / RM7A
TELEFUNKEN	TK2036	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
TELEFUNKEN	TK2037		CODIGO 2624 / FS 222 / MK6A
TELEFUNKEN	TK2069		2624
TELEFUNKEN	TK2069 ST		CODIGO 2624 / FS 222 / MK6A
TELEFUNKEN	TK2070		CODIGO 2624 / FS 222 / MK6A
TELEFUNKEN	TK2078		CODIGO 2624 / FS 222 / MK6A
TELEFUNKEN	TK2098		CODIGO 2792 / 00021E
TELEFUNKEN	TK2099		2792
TELEFUNKEN	TK2099ST		CODIGO 2792 / 00021E
TELEFUNKEN	TK2119ST		2792
TELEFUNKEN	TK2129 ST		CODIGO 2833
TELEFUNKEN	TK2129 STX	CODIGO 2787 ORIGINAL / RC83	CODIGO 2892 / RC135
TELEFUNKEN	TK2136 ST	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
TELEFUNKEN	TK2147STK		2787
TELEFUNKEN	TK2509ST		CODIGO 2792 / 00021E
TELEFUNKEN	TK2529STX	CODIGO 2787 ORIGINAL / RC83	CODIGO 2892 / RC135
TELEFUNKEN	TK2579ST		CODIGO 2624 / FS 222 / MK6A
TELEFUNKEN	TK2919ST		2792
TELEFUNKEN	TK2936		2657
TELEFUNKEN	TK2936 SN		CODIGO 2657 / RM7A
TELEFUNKEN	TK2969ST		CODIGO 2624 / FS 222 / MK6A
TELEFUNKEN	TK2999ST		CODIGO 2792 / 00021E
TELEFUNKEN	TKP2139ST		CODIGO 2833
TELEFUNKEN	TKP2147ST		CODIGO 2833
TELEFUNKEN	TKP2197S		3566
TELEFUNKEN	TKP2529ST		CODIGO 3130 / RM7A
TELEFUNKEN	TKP2919ST	PANTALLA PLANA	CODIGO 2792 / 00021E
TELEFUNKEN	TKP2929ST		CODIGO 3130 / RM7A
TELEFUNKEN	TKP2939ST		CODIGO 3130 / RM7A
TELEFUNKEN	TKP2947ST		CODIGO 3130 / RM7A
TELEFUNKEN	TKP2997S		3566
TELEFUNKEN	TKP3429ST		CODIGO 3130 / RM7A
TEL TEC	CT20RT		RC105
TIMEX	TI-8-14SLIMB		3514
TIMEX	TI-8-21SLIM		3514

TIMEX	TI-8-29SLIM		3514
TOKAY	CTK1430		CODIGO 2627 / RC1408
TOKAY	CTK1470M		CODIGO 2627 / RC1408
TOKAY	CTK2070M		2627
TONOMAC	29"		2642
TONOMAC	M2988		2642
TONOMAC	TO-1400 DP		POSIBLE RC 41
TONOMAC	TO-1496		2648
TONOMAC	TO-2004		CODIGO 2782 / RC41
TONOMAC	TO-2020		CODIGO 2648 / RC18147
TONOMAC	TO-2023	DVD MUY NUEVO	CODIGO 2648 / RC18147
TONOMAC	TO-2077		CODIGO 2725 / CCE
TONOMAC	TO-2096	R-18C30	CODIGO 2648 / RC18147
TONOMAC	TO-20V3		2449/2450
TONOMAC	TO-2100ST		CODIGO 2467
TONOMAC	TO-2942ST		CODIGO 2666 / AC2006 DUDOSO POSIBLE RC-55
TONOMAC	TO-2988 ST		
TONOMAC	TO-4-2141FT	PANTALLA PLANA	CODIGO 2666 / AC2006
TONOMAC	TO-4-2941 FT	PANTALLA PLANA	CODIGO 2666 / AC2006
TONOMAC	TO9814		2648
TOP HOUSE	1405		CODIGO 2782 / RC41
TOP HOUSE	1405		2481
TOP HOUSE	2004		2657
TOP HOUSE	2060	FS207	CODIGO 2624 / FS 222 / MK6A
TOP HOUSE	2060		2624 / 2657
TOP HOUSE	14TC628		2665
TOP HOUSE	20"		2481
TOP HOUSE	2004RS		2657
TOP HOUSE	2004R/5	T. DORMIR	CODIGO 2657 / RM7A
TOP HOUSE	20TC627		2665
TOP HOUSE	21N8D		2624
TOP HOUSE	25N8D	PANTALLA PLANA	CODIGO 2666 / AC2006
TOP HOUSE	29N8D	PANTALLA PLANA	CODIGO 2666 / AC2006
TOP HOUSE	29TH		2729
TOP HOUSE	37C1		CODIGO 2822 /
TOP HOUSE	54C1	PANTALLA PLANA	CODIGO 2822 / CODIGO2666
TOP HOUSE	74C1	PANTALLA PLANA	CODIGO 2822 / CODIGO2666
TOP HOUSE	CHASIS H613M		2481
TOP HOUSE	CTV1466	CODIGO 3149	CODIGO 2980 / CHASIS TV UNIV
TOP HOUSE	CTV1466NF		3149
TOP HOUSE	23456		2651/2727
TOP HOUSE	CTV2122		2727
TOP HOUSE	CTV2122NF	CODIGO 3149	CODIGO 2980 / CHASIS TV UNIV
TOP HOUSE	CTV2912		2727
TOP HOUSE	CTV2912PFS		CODIGO 2666 / AC2006 DUDOSO POSIBLE RC-55
TOP HOUSE	CV2122		3149
TOP HOUSE	HPS-1407		2725
TOP HOUSE	HPS-2007		2725
TOP HOUSE	HPS-2044	TIPO CCE	CODIGO 2725
TOP HOUSE	HPS-2076		2725
TOP HOUSE	HPS-2971		2725
TOP HOUSE	K21SA201L1		CODIGO 3522
TOP HOUSE	KP215A210LS		3522
TOP HOUSE	KP29TK		3522
TOP HOUSE	KP29TK210L3		

TOP HOUSE	TH2060	RD3100J / RC-U09	CODIGO 2657 / RM7A
TOP HOUSE	TH2060		2554
TOP HOUSE	TH2060M	RD3200	CODIGO 2783 / RM7A
TOP HOUSE	TH2160M	SD-SYSTEM CRUZ	CODIGO 2651 / RC55 / SD SYSTEM
TOP HOUSE	TH2180		2651
TOP HOUSE	TH2180M	SD-SYSTEM CRUZ	CODIGO 2651 / RC55 / SD SYSTEM
TOP HOUSE	TH2190		CODIGO 2657 / RM7A
TOP HOUSE	TH2960ST		2481
TOP HOUSE			CODIGO 3513 NUEVO
TOSHIBA	1467		2871
TOSHIBA	2067		2871
TOSHIBA	147R9L		2871
TOSHIBA	147T9LA	29CH	CODIGO 2871
TOSHIBA	152 RSAE	29 CH	CODIGO 2871
TOSHIBA	153 R6AE	29CH	CODIGO 2871
TOSHIBA	207T9LA	29CH	CODIGO 2871
TOSHIBA	21"	CARREFOUR	CODIGO 2657 / RM7A
TOSHIBA	2104TLA	39 CH	CODIGO 2440
TOSHIBA	2104TLA		2441
TOSHIBA	2125TLA	39 CH	CODIGO 2440
TOSHIBA	2125TLA		2441
TOSHIBA	212R6AE	29CH	CODIGO 2871
TOSHIBA	2131-TAE	100CH	CODIGO 2649
TOSHIBA	213R6AE	29CH	CODIGO 2871
TOSHIBA	2141TAE		2649
TOSHIBA	2141-TAE	100CH	CODIGO 2649
TOSHIBA	21ES7FS		
TOSHIBA	2829TL		2649
TOSHIBA	2918TL		2440/2441
TOSHIBA	3430DL		2649
TOSHIBA	C2048		TOSHIBA
TOSHIBA	CT9507	39 CH	CODIGO 2440
TOSHIBA	CT9507		2441
TOSHIBA	CX2779		CODIGO 2879
TOSHIBA	TV 14E97		CODIGO 2876
TOSHIBA	TV 20E97		CODIGO 2876
TOSHIBA	TV 2075		CODIGO 2876
TOWA			2649
TREVIS	TVR14		CODIGO 2978
TREVIS	TVR21	IGUAL ASAHI	CODIGO 2978
ULSTER			
ULTRASONIC			
VIEWSTAR			
VISIONEER	VX-50001V		CODIGO 2837
VISIONEER	VX-50002V		CODIGO 2837
WATSON	29156		3196
WATSON	TC2919HLA	NO HAY REEMPLAZO	
WATSON	TW-204M	RD3400	CODIGO 2784 / RM7A
WATSON	TW2901	RD3500	2990/2657
WELFUNG	2004		2657
WELFUNG	TC2929		2454
WELSOUND	GT8813A		CODIGO 2698 / RC105
WELSOUND	WD-210FS	SIMIL HOWLAND	CODIGO 2774
WEST PARK			
WESTINGHOUSE	205CR		2657

WESTINGHOUSE	252CR		2648
WESTINGHOUSE	293CR		2648
WESTINGHOUSE	32C		2823
WESTINGHOUSE	SAT142	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
WESTINGHOUSE	SAT143	NOBLEX SIN VIDEO	CODIGO 2469 / RC0402
WESTINGHOUSE	SAT145	RC6770/9145	CODIGO 2657 / RM7A
WESTINGHOUSE	SAT145		2438
WESTINGHOUSE	SAT205	RC6770/9145	CODIGO 2657 / RM7A
WESTINGHOUSE	SAT205		2738
WESTINGHOUSE	SAT321ST	RC6770/9145	CODIGO 2657 / RM7A
WESTINGHOUSE	SAT321ST		2738
WESTINGHOUSE	SL220	NOBLEX CON VIDEO	CODIGO 2475 / RC 105-2024
WESTINGHOUSE	T6201-WS		2657
WESTINGHOUSE	TG141WM		CODIGO 2657 / RM7A
WESTINGHOUSE	TG201	RD3100J	CODIGO 2657 / RM7A
WESTINGHOUSE	TG201 WSTCO 20"		2554
WESTINGHOUSE	TG201WM	RD3100J	CODIGO 2657 / RM7A
WESTINGHOUSE	TG201WM 20"		2554
WESTINGHOUSE	TG521 CRCO 21"		2554
WESTINGHOUSE	TM1021W		CODIGO 2782 / RC41
WESTINGHOUSE	TS1014W	RD3100J	CODIGO 2657 / RM7A
WESTINGHOUSE	TS1014W 14"		2554
WESTINGHOUSE	TS1020W		2792
WESTINGHOUSE	TV14" TG141 COE D/PARL		2554
WESTINGHOUSE	TV14" TS1014W		2554
WESTINGHOUSE	TV20" 201AMCO.E		2554
WESTINGHOUSE	TV20" TG201 WS C.O		2554
WESTINGHOUSE	WW114		CODIGO 2469 / RC0402
WESTINGHOUSE	WW114		2655
WESTINGHOUSE	WW145	SIN FUZZY	CODIGO 2657 / RM7A
WESTINGHOUSE	WW145		2738
WESTINGHOUSE	WW200		CODIGO 2557
WESTINGHOUSE	WW203		CODIGO 2657 / RM7A
WESTINGHOUSE	WW204	FUZZY	CODIGO 2657 / RM7A
WESTINGHOUSE	WW205	FORMA ORIGINAL CODIGO 2870	CODIGO 2657 / RM7A
WESTINGHOUSE	WW205		2738
WESTINGHOUSE	WW210		2667
WESTINGHOUSE	WW211		CODIGO 2667 / RC0422
WESTINGHOUSE	WW214		2557
WESTINGHOUSE	WW220	FORMA ORIGINAL = AL SAT202	CODIGO 2557
WESTINGHOUSE	WW221	FORMA ORIGINAL (CODIGO 2839)	CODIGO 2839 / CODIGO 2469 / RC0402
WESTINGHOUSE	WW221		2557
WESTINGHOUSE	WW252		CODIGO 2648 / RC18147
WESTINGHOUSE	WW293		2445
WESTINGHOUSE	WW320	FORMA ORIGINAL (CODIGO 2839)	CODIGO 2839 / CODIGO 2469 / RC0402
WESTINGHOUSE	WW320		2557
WESTINGHOUSE	WW321	RC6155/6145 (CODIGO 2870)	CODIGO 2657 / RM7A
WESTINGHOUSE	WW321		2738/2990
WESTINGHOUSE	WW3711	ORIG TECLAS COLOR	CODIGO 2580
WESTINGHOUSE	WW421	RC6155/6145 (CODIGO 2870)	CODIGO 2657 / RM7A
WESTINGHOUSE	WW421		2738
WESTINGHOUSE	WW521	RC6155/6145 (CODIGO 2870)	CODIGO 2657 / RM7A
WESTINGHOUSE	WW521		2738
WESTINGHOUSE	WW5511	ORIG TECLAS COLOR	CODIGO 2880
WESTINGHOUSE	WW7211	ORIG TECLAS COLOR	CODIGO 2580

WESTINGHOUSE	WX131MN		2648
WINCO	602		2435
WINCO	604		2435
WINCO	605		2435
WINCO	615		2435
WINCO	616		2435
WINCO	1860		2435
WINCO	5038		2435
WINCO	5314		2435
WINCO	32C	RC235	CODIGO 2823
WINCO	5051V		2435
WINCO	5314 ESTEREO		2475
WINS	W2048	CODIGO 2752 ORIGINAL	CODIGO 2782 / RC41
WINS	W2968	CODIGO 2752 ORIGINAL	CODIGO 2782 / RC41
WINS	WS1407		CODIGO 2878
WINS	WS2107		CODIGO 2878 / 3196
WINS	WS2108		CODIGO 3196
WINS	WS2907		CODIGO 3196
WINS	WS2907LY		CODIGO 2878
WINS	WS2908	NUEVO	CODIGO 3196
ZENITH	617D		2435
ZENITH	MBR3410		2699
ZENITH	SC2300		2699
ZENITH	SC3310		2699
ZENITH	SC3820		2699
ZENITH	todos los modelos		2699

REPRODUCTORES DE DVD			
MARCA	MODELO	OBSERVACIONES	MODELO DE REMOTO
3838	DVD-3838	PARECE VCD - ES DVD	CODIGO 2693 VCD
3838	DVD-3838		2693
1RT		DM2030	CODIGO 2762
ACOUSTECH	A-1070V	CODIGO 2798 ORIG / DVD826	CODIGO 2656
ACOUSTECH			CODIGO 2886
ACOUSTECH-AUDIOLOGIC	A-1070V		2656
ACOUSTECH-AUDIOLOGIC	AVD800		2859
ACOUSTECH-AUDIOLOGIC	DS-1050V		2656
ACOUSTECH-AUDIOLOGIC	DVD900		2656
ADMIRAL	AD-531		2759
ADMIRAL	AD-631		3142
ADMIRAL	AD-831		2760 - DVD801
ADMIRAL	ADM-434/77		2795 IGUAL 2765
ADMIRAL	ADM-436		2962
ADMIRAL	ADM-438X		2962
ADMIRAL	ADV-442/AK		2795 IGUAL 2765
ADMIRAL	AVD-423K		2795 IGUAL 2765
ADMIRAL	DV-5301		2758 - DVD803
ADMIRAL	DVA-807		2691 - DVD837
ADMIRAL	DVA-808	EL ORIG ES = AL BGH	CODIGO 2695 / CODIGO 2925
ADMIRAL	DVA-809		CODIGO 3557 - DVD278
ADMIRAL	DVA-810A CON USB		DVD278

AKAI	DVD-P2500		NO SE SABE REEMP
AKAI	DV-P6530K		2815 - DVD802
AKITA	DV-388		NOSE SABE REEMP
AKITA	DV-917		PROBAR CON 3142
AMTC	DV2025		2695
AMTC	DV3109		CODIGO 2758 - DVD803
AMTC	DV3109 CON USB		DVD278
AMTC	DV3607		DVD278
AMWOOD	AW-3000	BL046	CODIGO 2966
AMWOOD	AW4001		CODIGO 2966
ASAHI	DVD474A		3110
ASAHI	DVD474B		3110
ASAHI	DVD478D/A		3110
ASAHI	DVD871GS		CODIGO 3140
AUDINAC	AVD-1802		3116 - DVD656
AUDIOLOGIC	870S		2640
AUDIOLOGIC	AHT-160		2875
AUDIOLOGIC	AVD800		2859
AUDIOLOGIC	AVD-800	ORIGINAL CODIGO 2859	CODIGO 3136 / CODIGO 3137
AUDIOLOGIC	AVD-800		3136 / 3137
AUDIOLOGIC	AVD-850		3142
AUDIOLOGIC	AVD-870S		2640 - 827
AUDIOLOGIC	AVD-875	FORMA ORIGINAL	CODIGO 2692 - DVD807
AUDIOLOGIC	AVD-900	FORMA ORIGINAL	CODIGO 2640 - 827
AUDIOLOGIC	DVD001		2692
AUDIOLOGIC	DVD834		2814 - DVD834
AUDIOLOGIC		FORMA ORIGINAL	CODIGO 2814 - DVD834
AUDIOLOGIG		FORMA ORIGINAL	CODIGO 3142
AZAR	DVD-975		CODIGO 3125
BASIC LINE	DVD656		3116 - DVD656
BASIC LINE	DVD-BL51U		CODIGO 2797 - DVD810
BGH	BD701	CODIGO 2695 ORIGINAL	CODIGO 2925 / TELEFUNKEN
BGH	BD701Z	PALETITA NUEVO	
BGH	BD710HD		3595
BLAZE	DVD6800	FORMA ORIGINAL	CODIGO 2760 - DVD801
BLAZE	DVD6900		CODIGO 2760 - DVD801
BLAZE	IGUAL 3136 PERO NEGRO CON USB EN LUGAR DE N/P		CODIGO 3136 / CODIGO 3137
BLUESKY	AV-1001P		2761
BLUESKY	DV-133		3140
BLUESKY	DVD-211		2815 - DVD802
BLUESKY	DVD3010		2797 - DVD810
BLUESKY	DVD-681		2760 - DVD801
BOWMAR	BW-1010	CODIGO 2798 ORIG / DVD826	
BOWMAR	BW-1020		2875
BRANIFF			CODIGO 3176
CASA HOME	AV-01-248		3160 / 3167
CENTURY	DVD-158		POSIBLE 2762
CENTURY	JM-923		CODIGO 2762
COASTAR	CD-605		
COBY	615		2815
COBY	DVD-201		POSIBLE CODIGO 3142
COBY	DVD-201		3142
COBY	DVD-207		2987
COBY	DVD-209		2987
COBY	DVD-224		2741/3191

COBY	DVD-227	PROGRESIVE SCAN	CODIGO 2741
COBY	DVD-233		2987
COBY	DVD-514		2780 / DVD832
COBY	DVD-515		2799 - DVD809
COBY	TF-DVD4500		2988
COBY	TF-DVD7050		2988
CONTEX	DV133CS		3140
CONTEX	DVD-2029		3140
CONTINENTAL	DVD-3020		2780
CROWN JAPAN	CR-DVD460		NO SE SABE REEMP
CROWN JAPAN	DVD355	ORIGINAL MUY PARECIDO CON 2 TECLAS MENOS	CODIGO-3142
CYBERHOME	DVD-300		3184
DAEWOO	9000S5		3112
DAEWOO	DM-K405		DVD706
DAEWOO	DM-K503		DVD706
DAEWOO	DVDP480		2799
DAEWOO	DVG8400N		DVD706
DAEWOO	DWD282		2859
DAIHATSU	2005		2640 - DVD827
DAIHATSU	CON USB	IGUAL 3150 CON USB EN VEZ DE DISPLAY	
DAIHATSU	DVD2005		2800 - DVD811
DAIHATSU	DVD2005		3136
DAIHATSU	DV-D2005		2800 - DVD811
DAIHATSU	D-VD2008		2640 - DVD827
DAIHATSU	DVD2010		2800 - DVD811
DAIHATSU	DV-D2010	VERSION 2	CODIGO 2859
DAIHATSU	DV-D2015		2800 - DVD811
DAIHATSU	D-VD2025		3140
DAIHATSU	DVX-868		3137
DAIHATSU			CODIGO 3136 / CODIGO 3137
DAIHATSU			3136 / 3137
DATSUN	AHT150/165 (HOME)		2690
DATSUN	DHT100/115 (HOME)		2690
DATSUN	DVD-002		2691 - DVD837
DATSUN	DVD-002		2741
DATSUN	DVD-005		3140
DATSUN	DVD-006		3509
DATSUN	DVD-010	CODIGO 3140	CODIGO RC240
DATSUN	DVD-010		3114
DATSUN	DVDS130		3112
DATSUN	SIN MODELO	REMOTO IGUAL AL ORIGINAL	CODIGO 2692
DIAMOND			CODIGO 2758 - DVD803
DIGITAL	DVD683		CODIGO 2760
DIGITEL	DG-9322		2762
DIGITEL	DVD2009		2958
DIGITEL	DVD338		2798
DIGITEL	DVD4500		CODIGO 2765
DIGITEL	DVD4800		
DIGITEL	DVD683		2760
DIGITEL SONY TECHNOLOGY			2958
DIGIX MEDIA	DV228		2859
DIPLOMAT	DVD-300S51		3184
DIPLOMATIC	DVX-898 CON USB		CODIGO 3150 / CODIGO 3137
DIPLOMATIC	GM-1807		CODIGO 2691 PROBABLE
DR. HANK	DV-302B		

DR. HANK	DV-302B		
DURABRAND	DB-1500		3111
DURABRAND	DB-1700		2801
DURABRAND	DB-2700DVX	POSIBLES	CODIGO 3150 / CODIGO 3137
DURABRAND	DB-2700DVX		2925 (3150-3137)
DURABRAND	DB858	CODIGO 3150	CODIGO 3137
DURABRAND	DVD-2005		2730
DURABRAND	DV-DB55	NUEVO	CODIGO 3137
DURABRAND	DVX858		3150
DURABRAND	DVX-858		3137
DURABRAND	DVX-898		
DVCD	PLATINUM		CODIGO 2693
DVCD OSAYA	DVCD3288		CODIGO 2966
DVCD PREMIER	SS-3399		NO SE SABE REEMPLAZO
DVCD SKINA	VCD-329		CODIGO 3167
DVCD SKINA	W-981A		
ECO	EM-DVD-200		CODIGO 3169
EMBASSY	EM-1000DVX		3192
ENCORE	BT2511DVD		3189
ENCORE	DVD-817		
EOLITE	DVD4126		2802
ETEC	DVD926		CODIGO 2770 PERO TODAS FUNCIONES CAMBIADAS
ETEC			CODIGO 2987
ETEC			2987
EURO VIEW	EUDV121MK-SM		
EURO VIEW	EUDV862-N		2741
EUROMAX	DVD-4880		2760
FUJISTAR	DV-010B		REMOTO VCD REEMPLAZO
FUJISTAR	DV-010B		2693
FUJITEL	FDV-021		3142
FUJITEL	FJ-27000		2962
FUJITEL (DVCD)	FJ-60500		3161
FUNTIME			2640
FUSHIMI	DVD6884		3176
FUSHIMI	DVD-6884		3176
FUTURA	DVD3700S		CODIGO 2815
GAMA POWER	GP-DVD555		2875
GLOBAL HOME	DV-5007		CODIGO 2803 - DVD836
GLOBAL HOME	DV-5107		CODIGO 2758 - DVD803
GLOBAL HOME	K-123		2803 - DVD836
GLOBAL HOME	NO HAY MODELO		2758 - DVD803
GLOBAL HOME	RC901		2741
GOLDMUND	DV-5005		2758 - DVD803
GOLDMUND	DVD-K122		3116 - DVD656
GOTECH	DVD-3988		CODIGO 2761
GOTECH	JX-X6B		2761
GOWELL	DVX-681		2760 - DVD801
GOWELL	HTS864		CODIGO 2760 - DVD801
GOWELL	HTS-868		
GRANDA	OM-77		
GRANDA			CODIGO 3555
GRUNDIG	GDV-1008		CODIGO 2965
HISHI	BT2511DVD		2960 / TARGA IGUAL
HITACHI HITPLUS	DVC3838		2764
HITECH	DV-5307		2815

HITECH	DVD-4414		2692
HITPLUS	DV-C10		
HITPLUS	DV-C10		
HITPLUS	DV-C3838		2764 - DVD824
HITPLUS	DV-P643		3148
HITPLUS	DV-P741	ORIG. NEGRO	CODIGO 3148
HORIZON	NS-3069		2741
HORIZON	NS-4050		2741
HORIZON	NS-4050		2758 - DVD803
HORIZON			CODIGO 2803 - DVD836
HORIZON			2803 - DVD836
HOWLAND	CHICO BLANCO PORTATIL		CODIGO 3169
HOWLAND	HL-D918		3169
HOWLAND	HL-DV2		CODIGO 3169
HYPSON	NO HAY MODELO		2758 - DVD803
HYUNDAI	DP-3813		2815???
HYUNDAI	DVD-305		3562
HYUNDAI	HD2044		2815
HYUNDAI	HD-28	DVD-HOME	NOSE SABE REEMP
HYUNDAI	HDV-503		NO SE SABE REEMPLAZO
HYUNDAI	HU-DVD245		2859
IMPEX	DVCD8116		2958
IMPEX	VCD-2800		CODIGO 2966
IRT		DM2030	CODIGO 2762
JVC	TH-S11		
JVC	XV-N322S	FORMA ORIGINAL	CODIGO 2805 - DVD833
JVC XV	XV N332		2805
JVL	JV-888DVD		3167
JWIN	JD-VD501		2763
JWIN	JD-VD503		2731 - DVD830
KEN BROWN	DVD-200		
KNEISSEEL	DVD-681		POSIBLE 2760
KUDASAI	DVD-3801		2800 - DVD811
LG	DK-141		CODIGO 2804 / DVD835
LG	DP273B		2804
LG	DV140		CODIGO 2804 / DVD835
LG	DV235		CODIGO 2804 / DVD835
LG	DV360N		2804 / DVD835
LG	DVK-9733N		3148
LG	DVS-8521N		2804 / DVD835
LG	DVX172		
LG	DVZ-2511N		2804
LG	DVZ-9511N		2804 / DVD835
LG MAS HOME	LH-T252SC		
LG MAS HOME	LH-T252SC		
LYNX	DH-15	AM/FM	CODIGO 2814 - DVD834
LYNX	DVD-472		CODIGO 2925 / TELEFUNKEN
LYNX	DVD940		2758 - DVD803
LYNX	LY-651		3116 - DVD656
MAGNAVOX	MDV-411		2795
MAGNAVOX	MDV-434	IGUAL AL DE PHILIPS DVD	CODIGO 2795
MAGNAVOX	MDV-434		2758 - DVD803
MAGNAVOX	MDV435		2962
MAGNAVOX			2795
MAGNAVOX	MDV436		2962

MAGNAVOX	MDV-437		2962
MAKROSONIC	DIVX-3012		CODIGO 2966
MITSONI	AV-04-327		CODIGO 2815
MK TECH	DVD-028		2695
MK TECH	DVD-801		CODIGO 3578
MK TECH			2695/2925
NEVIR	NVR-2052 DVD/D		2875
NEW ONE	DV-2021		2692
NEW ONE	TF-108E		2692
NEW ONE	TF-108F3		2760 - DVD801
NEX	DVD3600P		NOSE SABE REEMP
NIPPON	DVD-3388		POSIBLE 2761
NISATO	DVD3819		2693
NISATO	DVD3918		3146
NISATO	DVD5005		2758 - DVD803
NISATO	DVU-1008		3146
NISATO	DVZ-105		2800 - DVD811
NISATO	DVZ-308		CODIGO 2925 / TELEFUNKEN
NOBLEX	1350 U		2764 - DVD824
NOBLEX	1450 U		2691 - DVD837
NOBLEX	1451 U		2691 - DVD837
NOBLEX	DVD-1150U		2818 / DVD228
NOBLEX	DVD-1250		2807
NOBLEX	DVD-1352		2764 - DVD824
NOBLEX	DVD-1450		2764
NOBLEX	DVD-1451U		2691
NOBLEX	DVD-1452		2758 - DVD803
NOBLEX	DVD-1553		3509/2758 - DVD803
NOBLEX	DVR-5406		2820
NOBLEX	DVU-200		2806 - DVD820
NOBLEX	1350 U		CODIGO 2764 - DVD824
NOBLEX	1450 U	TECLA POWER VERDE	CODIGO 2691 - DVD837
NOBLEX	1451 U	TECLA POWER VERDE	CODIGO 2691 - DVD837
NOBLEX	DVD-1150U		CODIGO 2818 / DVD228
NOBLEX	DVD-1352		CODIGO 2764 - DVD824
NOBLEX	DVD-1452	CODIGO-3516	CODIGO 2758 - DVD803
NOBLEX	DVD-1553	CODIGO-3516	CODIGO 2758 - DVD803
NOBLEX	DVD-1555A		CODIGO 3557 – DVD278
NOBLEX	DVH-1554A	CODIGO-3516	CODIGO3516
NOBLEX	DVR-5406	REPRODUCE Y GRABA DVD	CODIGO 2820
NOBLEX	DVU-200	TIENE RADIO FM/AM	CODIGO 2806 - DVD820
NORCENT	DP312		3136
NORCENT	DV-300		2859
NTC	DVD-Z668	POSIBLE 2837	
OMIYA	7007		2760 - DVD801
OMIYA	7008		2760 - DVD801
OMIYA	OM 7001 AR		2760 - DVD801
OMIYA	OM-7003AR		2760
OMIYA	OM-7007AR		CODIGO 2760 - DVD801
OMIYA	OM-7009AR		2760 - DVD801
OMIYA	OM-8011		2760 - DVD801
OMIYA	OM-8900DVD		2760 con funciones camb.
OMIYA	OM-9941		2693 VCD
OMIYA	OM-9959 AR		2765 - DVD842
OMIYA	OM-9977 ARD		POSIBLE 2765

OMIYA	OM-9979 ARD		POSIBLE 2765
OMIYA	OM-9980		2765 - DVD842
OMIYA	OM-9982		2765 - DVD842
OMIYA	OM-9983		2765 - DVD842
OMIYA	OM-AC-381DVD		NOSE SABE REEMP
ORICA	DVD-003		2765
ORICA	DVD-010B		2765 - DVD842
OSAYA	VCD-380A		CODIGO 2767 (PARA SONY)
OSAYA	VCD-392		CODIGO 2767 (PARA SONY)
PACIFIC	DV-1088		CODIGO 2762
PAGODA	PGD-996		CODIGO 2760
PAGODA	PGV-609		2760
PANASONIC	DVD-S27	FORMA ORIGINAL	CODIGO 2808 - DVD821
PANASONIC	DVD-S29	FORMA ORIGINAL	CODIGO 2808 - DVD821
PANAVOX	MDV4334/77		2795
PANORAMIC	225		CODIGO 2800 - DVD811
PANORAMIC	DVD-178		3112
PANORAMIC	DVD-P2401		2800 - DVD811
PANORAMIC	DVDP-2406U		CODIGO 2800 - DVD811
PANORAMIC	PR-DVD178		3117
P-D	CON VIDEOJUEGO	PROBAR 3507	CODIGO 2692 - DVD807
PECONIC	X-081		CODIGO 2760
PHILCO	DV-393S		2659 - DVD816
PHILCO	DVH-429A		CODIGO 3557 - DVD278
PHILCO	DVP-401U		2818 / DVD228
PHILCO	DVP402U		2807 DVD1250U
PHILCO	DVP403U		2764 - DVD824
PHILCO	DVP404U		CODIGO 2691 - DVD837
PHILCO	DVP-415		2691 - DVD837
PHILCO	DVP-418		3531
PHILCO	DVP-419		CODIGO 3531
PHILIPS	DVD3160		3171
PHILIPS	DVD625		2567
PHILIPS	DVD703		2567
PHILIPS	DVD711		2567
PHILIPS	DVP-3005		2567
PHILIPS	DVP-3010	CHICO BLANQUITO	CODIGO 3171
PHILIPS	DVP-3020		3171
PHILIPS	DVP-3040K	CHICO BLANQUITO	CODIGO 3171
PHILIPS	DVP-3111		
PHILIPS	DVP-3120	CHICO BLANQUITO	CODIGO 3171
PHILIPS	DVP-3120		3171
PHILIPS	DVP-3142		3171
PHILIPS	DVP-320/78		2567 / 2795 / DVD812
PHILIPS	DVP-320/AK		2567 / 2795 / DVD812
PHILIPS	DVP-3254		CODIGO 3171
PHILIPS	DVP-3320	CHICO BLANQUITO	CODIGO 3171
PHILIPS	DVP-3500	REMOTO GRIS	CODIGO 2567
PHILIPS	DVP-350P		CODIGO 2567
PHILIPS	DVP3980KX/77	CHICO BLANQUITO	CODIGO 3171
PHILIPS	DVP5-100K		2567
PHILIPS	DVP-530AK		2567 / 2795 / DVD812
PHILIPS	DVP-642K/78		2567 / 2795 / DVD812
PHILIPS	HTS6500 (HOME)		3173
PHILIPS	MX2600	DVD+HOME	CODIGO 3173

PHILIPS			3173
PHILMORE			2803 - DVD836
PIONEER	DV-353		CODIGO 2659 - DVD816
PIONNER	DV-414		2659 - DVD816
PIONNER	DVP404U	TECLA POWER VERDE	CODIGO 2691 - DVD837
PRECISION	PVD-5190SM		2875
PREMIER	SX-005DVDR	CON KARAOKE	NO SE SABE REEMP
PREMIER	SX-0797D		2837
PREMIER	SX-0871D		2837
PREMIER	SX-1457D		2780
PREMIER	SX-1475D		2966
PREMIER	V-1018M		2837
PREMIER	V1616M		2837
PREMIER	V-1728D		2837
PRO-AUDIO	PA-250DVD		PROBAR 2797
PRO-AUDIO	PA-300DVG		
PROLINE	DVD838 SLIM		POSIBLE 3143
PROLINE			CODIGO 2814 IGUAL 3143
PRONEXT	4600		CODIGO 2771
PRONEXT	4700		CODIGO 2771
PRONEXT	4800		CODIGO 2771
PRONEXT	8800		CODIGO 2771
PROTON	PD-007		3137
PROTON	PD-800		3136
PROTON	PD-800		3168
RANSER	DVD-1122		2815 - DVD802
RANSER	DVD-1166	FORMA ORIGINAL	CODIGO 2815 - DVD802
RANSER	DVD-838S	FORMA ORIGINAL	CODIGO 2814 - DVD834
RANSER	DVD-923		2693
RANSER	DV-RA22		2815
RANSER	DV-RA44	CON USB	CODIGO 3511
RANSER	DV-RA66	FORMA ORIGINAL	CODIGO 2815 - DVD802
RANSER	DV-RA90		3140
RANSER	DV-RA90		3114
RCA	100LAR		2816
RCA	DRC-010AR		AVERIGUAR
RCA	DRC-015AR		CODIGO 3148
RCA	DRC-016AR		CODIGO 3148
RCA	DRC-122AR	COMO HOWLAND	CODIGO 3148
RCA	DRC-303 USB		CODIGO 3148
RCA	RDV-8100 DSK-M		2817
RCA			3148
RECCO	9200		NO VA EL 2814
RECCO	9200		ORIG PARECIDO AL 2814
RITECH	RJ-3700		2801 / 817
RITECH	RJ-700DVX		2801 / 817
RYSOUND	DVD-800		POSIBLE 3141 DAEWOO
SAMSUNG	DVD-P172		CODIGO 2732 / DVD818
SAMSUNG	DVD-P182		CODIGO 2732 / DVD818
SAMSUNG	DVD-P192		2732 / DVD818
SAMSUNG	DVDP543K		2732
SAMSUNG	P-250K		2732 / DVD818
SANSEI	DVP-404		CODIGO 2691 - DVD837
SANSEI	DVS-2020		2800 - DVD811
SANSEI	DVS-801U	TECLA POWER VERDE	CODIGO 2691 - DVD837

SANSEI	DVS-803	TECLA POWER VERDE	CODIGO 2691 - DVD837
SANYO	9205 U		2764 - DVD824
SANYO	9206 U		2691 - DVD837
SANYO	DC-DA213 DAX213		CODIGO 2809 - DVD814
SANYO	DCTS-5220		2809 - DVD814
SANYO	DCTS-5232U		2809 - DVD814
SANYO	DCTS-5233		2809 - DVD814
SANYO	DCTS-5240U		2809 - DVD814
SANYO	DCTS-5252U		2809 - DVD814
SANYO	DCTS-6010		CODIGO 2809 - DVD814
SANYO	DVD-9100U		2818
SANYO	DVD-9105U		CODIGO 2807 DVD1250U
SANYO	DVD-9106U		CODIGO 2764 - DVD824
SANYO	DVD-9307		CODIGO 2691 - DVD837
SANYO	DVD-9408		CODIGO 3516
SANYO	DVD-9408		2758 - DVD803
SANYO	DVH-9207U	HDMI	CODIGO 3516
SANYO	DVH-9207U		2758 - DVD803
SANYO	DVH-9208		2758 - DVD803
SANYO	DVH-9209	HDMI	CODIGO 3516
SANYO	DVH-9309	HDMI	CODIGO 3557 - DVD278
SANYO	DVR5406V		2820
SANYO	DVR960		2820
SANYO	DVR-960U		2820
SANYO	DWM-400		CODIGO 3518 - UNIV- CODIGO 233
SHARP	DV595		2815 - DVD802
SHARP	DV-S1		NOSE SABE REEMP
SHARP	DV-S1		NOSE SABE REEMP
SHARP	DV-S5		NOSE SABE REEMP
SHARP	DV-S5		NOSE SABE REEMP
SHARP	WJ-1000DV		2770
SHARP	WJ-2000DV		2770
SHARP	WJ-3000DV		2770
SHARP	WS 33		2815 - DVD802
SHARP	WS 595		2815 - DVD802
SHARP	WS-3700		2813 - DVD831
SHARP	WS-3900		2813 - DVD831
SHARP	WS-8300		3183
SHARP	WS-9300		3183
SILVER KING	SK-630		2760 - DVD801
SILVER POINT JAPAN	DVD-9001K		2837
SKINA	W-981A		
SOLTECH	SL1000		2780 / DVD832
SOLTECH	SL1001		3160
SOLTECH	SL2000		2859
SOLTECH	SL3000	FORMA ORIGINAL	CODIGO 2780 / DVD832
SONIVOX	DVD-015		2780 / DVD832
SONIVOX	DVD-050		CODIGO 3168
SONIVOX	DVD-810		2780 / DVD832
SONIVOX	VS-DVD393		3168
SONY	DVD-60000	PROGRESSIVE SCAN	CODIGO 2966
SONY	DVD-9909		2801
SONY	DVD-NS575P		2835
SONY	DVP-NS32S		??
SONY	DVP-NS32S		??

SONY	DVP-NS508P		CODIGO 2766 / DVD819
SONY	DVP-NS50P		2766 / DVD819
SONY	DVP-NS57P		2766 / DVD819
SONY	DVP-SR200P		CODIGO 2766 / DVD819
SONY	OM7000AR		2760
SONY TECHNOLOGY	OM-7012		CODIGO 2760 - DVD801
SPACIAL	SP-100	CODIGO 2798 ORIG / DVD826	CODIGO 2656
SPACIAL			CODIGO 2803 - DVD836
SPALTEC	SP-DVD2000		2765 - DVD842
SPARKOMATIC	SP830		2758 - DVD803
SPARKOMATIC	SPA-960		2758 - DVD803
SPICA		IGUAL A PREMIER	CODIGO 2837
STARLIGHT	DV-3000		CODIGO 2771
STARMAX	ST908		CODIGO 2760 - DVD801
STEELHOME	SH-2700(U)		CODIGO 2800
STROMBERGCARLSON	AR-2640	PARECIDO BGH	
STROMBERGCARLSON	BFM-205		3555
STROMBERGCARLSON	DVD-563		2815 - DVD802
STROMBERGCARLSON	DVD-652		3116 - DVD656
STROMBERGCARLSON	DVD-658		3116 - DVD656
STROMBERGCARLSON	DVD-659	PARECIDO BGH	
STROMBERGCARLSON	DVD-664	dvd	2768
STROMBERGCARLSON	DVD-983	FORMA ORIGINAL	CODIGO 2815 - DVD802
STROMBERGCARLSON	SC-661		CODIGO 2765
STROMBERGCARLSON	SC-662		
SUMISHI	SUMDVD101		
SUZUKI	DVS-3000	PARECIDO 3110 DE FORMA	CODIGO 2692
SUZUKI			CODIGO 3161
TAGWOOD	DVD01A		TODAVIA NO HAY REEMP
TAGWOOD	DVD01A		TODAVIA NO HAY REEMP
TAGWOOD	SIN MODELO		CODIGO 2815
TAKATA	TKT934		2959
TAKUMA	DVD-2207		2802
TAKUMA	DVD-4301		2811 / 2800
TAKUMA	DVD-801		3159 / 3508
TAKUMA	DVD-806		3159
TAKUMA	DVD-806		2760
TAKUMA	DVD-8811		2811 / 2800
TAKUMA	DVD-9922		2811 / 2800
TAKUMA	DVD9922X		2811
TAKUMA	DVX-052		2811 / 2800
TAKUMA	DVD-2207	IGUAL AL EOLITE	CODIGO 2802
TAKUMA	DVD-4301		CODIGO 2811 / CODIGO 2800
TAKUMA	DVD-801	OTRA VERSION	CODIGO 2760
TAKUMA	DVD-801		CODIGO 3159 = CODIGO 3508
TAKUMA	DVD-806		CODIGO 3159 = CODIGO 3508
TAKUMA	DVD-806	OTRA VERSION	CODIGO 2760
TAKUMA	DVD-806	OTRA VERSION	CODIGO 2692
TAKUMA	DVD-8811		CODIGO 2811 / CODIGO 2800
TAKUMA	DVD-9922		CODIGO 2811 / CODIGO 2800
TAKUMA	DVX-052		CODIGO 2811 / CODIGO 2800
TALENT	DSX550		2800 - DVD811
TALENT	DSX650		TODAVIA NO HAY REEMP
TALENT	DSX650		TODAVIA NO HAY REEMP
TALENT	DVD1038H		2814

TARGA	NO HAY MODELO	CODIGO 2960 ORIGINAL	CODIGO 2888 / HISHI IGUAL
TCL	DVD-211		3148
TCL	DVD-212USB		CODIGO 3148
TCL	DVD-503HD		dd
TCL	HT-51		
TELEFUNKEN	NO HAY MODELO	CODIGO 2925 ORIGINAL	CODIGO 2695 / BGH
TELEFUNKEN	TK6029		2925
TELEFUNKEN	TK6039Z		CODIGO 2925 / TELEFUNKEN
TELEFUNKEN	TK619		CODIGO 2925 / TELEFUNKEN
TONOMAC	DV-026		2803
TONOMAC	DV-9500		2806
TONOMAC	DVI-515		CODIGO 2925 / TELEFUNKEN
TONOMAC	DVT505A		CODIGO3557
TOP HOUSE	DVD1800		3533
TOP HOUSE	DVD-1800 CON USB		CODIGO 3533
TOP HOUSE	HD830		3179
TOP HOUSE	HD831	FORMA ORIGINAL	CODIGO 2812 - DVD804
TOP HOUSE	HD832		2812
TOP HOUSE	ID538	FORMA ORIGINAL	CODIGO 2769 - DVD806
TOP HOUSE	ID538		2692
TOP HOUSE	ID568	FORMA ORIGINAL	CODIGO 2769 - DVD806
TOP HOUSE	ID588		CODIGO 2769 - DVD806
TOP HOUSE	ID800		CODIGO 2769 - DVD806
TRENT	3351	?????	????
TRENT	3351		????
TREVIS	TVR-3501DVD		NO SE SABE REEMP
TREVIS	VS-666		2692 - DVD807
TRIMAX	VS444VCD		2767
TRITONE	TS-1100 STD		NO SE SABE REEMP
VCD JACKSON	VCD-1385		CODIGO 3167 (CODIGO2797)
VCD JMD	VCD-380A		CODIGO 2958
VCD SONY	TV-111DVCD		CODIGO 3167 (CODIGO2797)
VCD WINS	WS-760		CODIGO 2693
VEMMAX			
VOXSON	DV-011		2815
VOXSON	DV-014		CODIGO 2758 - DVD803
VOXSON	DV-015		CODIGO 2758 - DVD803
VOXSON	DV-016		CODIGO 2815
VOXSON	DV-11		2770
VOXSON	DVX-90		2758 - DVD803
VOXSON			CODIGO 2831 - DVD838
VSONIC	DVP6000PS		3112
VTRACKI			2958
VTREK	DVD-K32	OTRA VERSION	CODIGO 3507
VTREK	DVD-K32		2692 - DVD807
WATSON	DV-3840		2815 - DVD802
WATSON	DV-5009		2758 - DVD803
WATSON	DVD008	FORMA ORIGINAL	CODIGO 2831 - DVD838
WATSON	SY-863		CODIGO 3511
WINCO	DVD-1908	USB	?????
WINCO	DVD-615		3139
WINCO	W-872	CODIGO 3136	CODIGO 3137
WINCO	W-878	CODIGO 3136	CODIGO 3137
WINCO	W-879	CODIGO 3136	CODIGO 3137
WINS	502		

WINS	DV595	FORMA ORIGINAL	CODIGO 2815 - DVD802
WINS	VCD-329	FORMA ORIGINAL	CODIGO 2813 - DVD831
WINS	WJ-1000DV	CODIGO 2771 ??????????	CODIGO 2770
WINS	WJ-2000DV	FORMA ORIGINAL	CODIGO 2770
WINS	WJ-3000DV	FORMA ORIGINAL	CODIGO 2770
WINS	WS 311		
WINS	WS 33	FORMA ORIGINAL	CODIGO 2815 - DVD802
WINS	WS 533 USB		
WINS	WS 595	FORMA ORIGINAL	CODIGO 2815 - DVD802
WINS	WS-231 USB	USB	CODIGO 3183
WINS	WS-3700	FORMA ORIGINAL	CODIGO 2813 - DVD831
WINS	WS-3900	FORMA ORIGINAL	CODIGO 2813 - DVD831
WINS	WS-3900 N		2813
WINS	WS-610USB		CODIGO 2815
WINS	WS-612USB		CODIGO 2815
WINS	WS-8300	DIVX	CODIGO 3183
WINS	WS-9300	USB	CODIGO 3183
X VIEW	AD-2020		2800 - DVD811
X VIEW	DVD-959		2961
X VIEW	DX-101		2691
X VIEW	DX-101		3138
X VIEW	RG-500		2961
X VIEW	RG-500		2760 - DVD801
X VIEW	RG-535		2961
X VIEW	RG-570		2799
X VIEW	RG-575		2691
X VIEW	RG-929		2741
X VIEW	RG-959		2760
X VIEW	RG-979		3142
X VIEW	RG-979		2760 - DVD801
X-VIEW	AD-2020		CODIGO 2800 - DVD811
X-VIEW	DVD-959	FORMA ORIGINAL	CODIGO 2961
X-VIEW	DX-101		CODIGO 3138
X-VIEW	DX-101	OTRA VERSION	CODIGO 2691 - DVD837
X-VIEW	RG-500	OTRA VERSION	CODIGO 2760 - DVD801
X-VIEW	RG-500	FORMA ORIGINAL	CODIGO 2961
X-VIEW	RG-535	FORMA ORIGINAL	CODIGO 2961
X-VIEW	RG-595		CODIGO 3138
X-VIEW	RG-929		CODIGO 2741
X-VIEW	RG-959		CODIGO 2760
X-VIEW	RG-979		CODIGO 3142
X-VIEW	RG-979	OTRA VERSION	CODIGO 2760 - DVD801
YAMASAKI	DVP-9C2K		3112
YOKOHAMA	YK-3000		2780 / DVD832
YOKOHAMA	YK326		
YOKOHAMA	YK326		
YOKOHAMA	YK3818		2780
ZEEMUNDO	3988		2765 - DVD842
ZEEMUNDO	DVD-9003 K		NOSE SABE REEMP
ZEEMUNDO	DVD-9003 K		NOSE SABE REEMP
ZUZUKI	DVCDVD-011		CODIGO 2693 VCD
	DVD656	FORMA ORIGINAL	CODIGO 3116 - DVD656

CONVERSORES CATV			
MARCA	MODELO	OBSERVACIONES	MODELO DE REMOTO
ANTINA	TODOS		CODIGO 3197 / CODIGO 3198
CABLEVISION			CODIGO 3153
COMTEC	CP-2863	CABLEVISION	CODIGO 2874
COMTEC		MULTICANAL	CODIGO 2874
CONVERSOR	ASC7000		CODIGO 2873
DIRECT TV	BLANCO		CODIGO 2830
DUMONT			CODIGO 2827
GENERAL INSTRUMENT	CFT2200	RC760	LL-1205
GENERAL INSTRUMENT	2000/2200		CODIGO 2457
GENERAL INSTRUMENT	5506W		CODIGO 2772
GENERAL INSTRUMENT	RC550		CODIGO 2734
HISHI	HC-65		CODIGO 2874
JEB ROWLAND	EME-300		CODIGO 2726
JEBSEE	EU-SCC70		CODIGO3592
JERROLD	5507MU	CONVERSOR 3 TECLAS	CODIGO 2772
JERROLD		CONVERSOR 20 TECLAS	CODIGO 2734
MITSUKAWA	SL600		CODIGO 2827
MITSUKAWA	8155T		CODIGO 2827
MOON			CODIGO 2827
MULTICANAL	TELERED/MULTICAL		CODIGO 3521
NOGA	2005		CODIGO 2726
PX	SC88N	CON VOLUMEN	CODIGO 2828
TEEC			CODIGO 2827
TELECENTRO			CODIGO 3162
V-TECH	MULTICANAL		CODIGO 2873

REPRODUCTORES VHS			
MARCA	MODELO	OBSERVACIONES	MODELO DE REMOTO
VCR ADMIRAL	VHR-A401P		CODIGO 2638
VCR CONTINENTAL	VCR-1870AN	ORIGINAL VARIAS MARCAS (SAMSUNG-PHILIPS-CONTINENTAL) CON TAPITA DESLIZABLE	CODIGO 2685 / GOLDSTAR
VCR DAEWOO	DVR-8280A		CODIGO 2834
VCR GOLDSTAR	RG21A		CODIGO 2685 / GOLDSTAR
VCR ITT NOKIA	9000HQ		CODIGO 2579 ITT NOKIA
VCR JVC	J48		CODIGO 2558
VCR JVC	HR-J472EN		CODIGO 2558
VCR NOBLEX	VCR706		CODIGO 2579 ITT NOKIA
VCR NOBLEX	VCR722		NO HAY REEMP
VCR NOBLEX	VCR794		CODIGO 2579 ITT NOKIA
VCR PANASONIC	NV-SD440		CODIGO 2647
VCR PANAVOX	5088		CODIGO 2650
VCR PHILCO	VPM-404	4 HEADS	NO HAY REEMP
VCR PHILIPS	VR-615		CODIGO 2654
VCR SANYO	VHR-5200	(ORIGINAL PARECIDO AL DE TV 2839)	CODIGO 2579 ITT NOKIA
VCR TALENT	TVP-9404		CODIGO 2579 ITT NOKIA
VCR TELEFUNKEN	VCR8500	ORIGINAL VARIAS MARCAS (SAMSUNG-PHILIPS-CONTINENTAL) CON TAPITA DESLIZABLE	CODIGO 2685 / GOLDSTAR



Copyright © 2014 - Todos los derechos reservados
ElReyDelRemoto.com.ar es una división de Soluciones Electrónicas S.R.L.
Panamá 925 - Ciudad de Buenos Aires - Telefonos (011) 6091-3037 / 6379-6583